

Philips
Universal remote control

SRU6061



Sleek, new metal series

with chrome top.

New elegant design features 6 device operation, learning functionality and advanced DVD and satellite features. Easy to set up and use with permanent memory retention.

Enjoy advanced DVD functions

- Easy access to subtitle, zoom and repeat function
- Chapter +/- and chapter scan for ease of use

Enjoy advanced satellite functions

- Guide, info/select, quit, OK and scroll
- Easy keypad design for ease of use

Enjoy advanced TV functions

- Advanced PIP with toggles for ease of use
- Convenient sleep timer
- Volume/Mute punch through for ease of use
- Closed caption for ease of use
- Input choices

Enjoy complete control over your components

- Complete menu functions
- Quickly copy features and functions from existing remotes

PHILIPS
sense and simplicity

Specifications

Convenience

- Supported devices: TV, VCR, DVD, SAT, CABLE, CD/MD, RECEIVER, AMP, TV-DVD, TV-VCR, DVR
- Languages in manual: English, French, Spanish

Infrared Capabilities

- Learning IR codes

Power

- Battery type: AAA / LR03 Alkaline
- Battery saving manager: Auto switch on/off
- Number of batteries: 2

Packaging Data

- EAN/UPC/GTIN: 6 09585 13570 3
- Gross weight: .2 kg
- Height: 30 mm
- Length: 275 mm
- Width: 110 mm

Inner Carton

- EAN/UPC/GTIN: 1 06 09585 13570 0
- Gross weight: .91 kg
- Height: 120 mm
- Length: 290 mm
- Quantity: 4
- Width: 125 mm

Highlights

Advanced PIP with toggle

Allows you to switch back and forth between two channels from two different tuners.

Subtitle, zoom, repeat buttons

Enjoy complete access to your DVD features: view subtitles, and repeat scenes at the touch of a button.

Chapter +/- and chapter scan

Easily locate and scan the succeeding or preceding chapters on a disc at the touch of a button.

Sleep timer

Programmable to shut off the TV anywhere from 1 to 99 minutes. Will act as a sleep timer for any TV with or without a sleep timer.

Volume/Mute punch through

Eliminates the need to switch back to TV mode to control volume and mute functions

Closed caption

Conveniently displays program dialogue as on-screen text. It will only work with TVs equipped for closed captioning.

Guide, info/select and scroll

Enjoy all your satellite system has to offer. Features allow you to access on-screen satellite channel guide, info, select/OK, quit, and scroll to easily navigate through the guide.

Easy keypad design

Convenient ergonomic access to all features and functions of the remote control makes it easy to access and operate.

Input choices

Allows you to select from available viewing sources

Menu

The ability to access each component menu and set up the component to your needs.

Quick learning

The ability to copy favorite features and functions from existing remotes. Remotes are placed head to head and codes are transferred from one to another.



Issue date 2010-09-01

Version: 4.2.11

12 NC: 8670 000 31501
UPC: 6 09585 13570 3

© 2010 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com