

Philips
Sleek DVD micro system



MCD263



Bring cinema experience to life

The sleek, wall-mountable Philips DVD micro system MCD263 offers a clutter-free, movie experience at home. With Dolby Virtual Speaker technology and HDMI video output up to 1080p, it delivers cinema-like surround sound and sharp images

Enrich your movie experience

- Dolby Virtual Speaker for theater audio experience
- HDMI 1080p upscales to high definition for sharper pictures
- Play DVD, DivX® Ultra, (S)VCD, MP3/WMA-CD(RW) & Picture CD

Enrich your sound experience

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- Total 60W RMS / 1200W PMPO
- USB Direct for photos and MP3/WMA music playback

Design that blends into your interior(s)

- Stylish slim design with table-stand and wall-mount options
- Motorized sliding front door adding style and elegance

PHILIPS

Highlights

HDMI 1080p



HDMI 1080p upscaling delivers images that are crystal clear. Movies in standard definition can now be enjoyed in true high definition resolution - ensuring more details and more true-to-life pictures. Progressive Scan (represented by "p" in "1080p") eliminates the line structure prevalent on TV screens, again ensuring relentlessly sharp images. To top it off, HDMI makes a direct digital connection that can carry uncompressed digital HD video as well as digital multichannel audio, without conversions to analog - delivering perfect picture and sound quality, completely free from noise.

Dolby Virtual Speaker

Dolby Virtual Speaker is a sophisticated audio virtualization technology that produces rich and immersive surround sound from a two-speaker system. Highly advanced spatial

algorithms faithfully replicate the sonic characteristics that occur in an ideal 5.1-channel environment. DVD playback is enhanced by expanding the 2-channel environment. When combined with Dolby Pro Logic II processing, any high quality stereo source is transformed into true-to-life, multi-channel surround sound. No need to purchase extra speakers, wires or speaker stands to appreciate room-filling sound.

Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your

music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Specifications

Picture/Display

- Picture enhancement: Video upscaling, High Def (720p, 1080i, 1080p)

Sound

- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost, Loudness
- Sound System: Dolby Digital, Dolby Virtual speaker
- Output Power: 2x10W + 40W (RMS)

Loudspeakers

- Main Speaker: 3" woofer
- Subwoofer type: Active

Video Playback

- Playback Media: DivX Ultra, DVD-Video, Video CD/SVCD, DVD+R/+RW, DVD-R/-RW
- Disc Playback Modes: A-B Repeat, Angle, PBC, Parental control, Disc Menu, Fast Backward, Fast Forward, OSD, Zoom, Resume Playback from Stop, Slow Motion
- DVD Region.: 3
- Loader Type: Motorised
- Video Enhancement: Progressive Scan

Still Picture Playback

- Picture Compression Format: JPEG
- Playback Media: CD-R/RW, DVD+R/+RW, Picture CD

Audio Playback

- Playback Media: MP3-CD, WMA-CD, CD, CD-R, CD-RW
- Disc Playback Modes: Repeat/one/all/program, Shuffle Play, 20-Track Programmable
- ID3-tag support
- Loader Type: Motorised
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Shuffle, Stop

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- Station presets: 20
- Tuner Enhancements: Auto Store

Connectivity

- AV output: Ext 3.5 mm jack x1
- Aux in: 3.5 mm (MP3 Link)
- Other connections: FM Antenna, HDMI out, Subwoofer out
- USB: USB host
- Headphone: 3.5 mm

Convenience

- Alarms: CD Alarm, Sleep timer, Radio Alarm, USB alarm
- Clock: On main display
- Display Type: LCD
- OSD Languages: English, Thai, Traditional Chinese
- Indications: DIM mode
- Wall mountable / Ceiling Throw: Wall Mountable

Accessories

- Included accessories: Audio/Video cable, Screws for wall mounting x2, World Wide Warranty leaflet
- User Manual
- Quick start guide
- Remote control: 40-key with Lithium batteries

Dimensions

- Set dimensions (W x H x D): 542 x 238 x 102 mm
- Packaging dimensions (W x H x D): 600 x 400 x 308 mm
- Subwoofer dimensions (W x H x D): 170 x 197 x 302 mm
- Set weight: 7.1 kg
- Weight incl. Packaging: 8.8 kg

Power

- Power supply: 110-240V, 50/60 Hz



Issue date 2013-05-10

Version: 1.0.5

12 NC: 8670 000 59558
EAN: 87 12581 52247 6

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com