

Philips  
DVD player

DVP3136



## Simply plays it all

With built-in digital amplifier

Your dream player with flawless, true-to-life picture quality and the ability to play virtually any disc! The Philips DVD player delivers your movies and music entertainment experience.

### **Bring audio and video to life**

- 12-bit/108MHz video processing for sharp and natural images
- 192kHz/24 bit audio DAC enhances analogue sound input
- High quality outputs for analog and digital audio
- Progressive Scan component video for optimized image quality
- 5.1 audio and stereo output for multiple connections

### **Fits any space, any lifestyle**

- Ultra-slim design that fits anywhere

### **Play all your movies and music**

- Plays MP3, WMA and JPEG digital camera photos
- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW

**PHILIPS**  
sense and simplicity

# Highlights

## Plays it all

Play MP3s, WMA and JPEGs, and experience the convenience of sharing media files on your TV or home theater system - in the comfort of your living room.

## 192kHz/24 bit audio DAC

192KHz sampling enables you to have an accurate representation of the original sound curves. Together with a 24-bit resolution,

more information is captured from the original analogue sound wave form, giving a much richer audio reproduction.

## Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both

fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

## 5.1 audio and stereo output

5.1 audio and stereo output for multiple connections

12-bit  
Video DAC



# Specifications

## Picture/Display

- D/A converter: 12 bit, 108 MHz
- Picture enhancement: Progressive scan, Video upsampling

## Sound

- D/A converter: 24 bit, 192 kHz
- Frequency response: 30-20000 Hz
- Signal to noise ratio: 90
- Crosstalk (1kHz): 70 dB
- Dynamic Range (1kHz): 80 dB
- Distortion and Noise (1kHz): 65 dB
- Sound System: Dolby Digital

## Video Playback

- Playback Media: CD-R/CD-RW, DVD-R/-RW, DVD+R/+RW, DVD-Video, Video CD/SVCD, CD, DVD
- Compression formats: MPEG1, MPEG2
- Video disc playback system: NTSC, PAL

## Audio Playback

- Playback Media: Audio CD, CD-R/RW, CD, MP3-CD, MP3-DVD, WMA-CD
- Compression format: MP3, WMA, Dolby Digital, PCM
- MP3 bit rates: 32 - 320 kbps

## Still Picture Playback

- Playback Media: CD-R/RW, DVD+R/+RW, DVD-R/-RW, Kodak Picture CD, Picture CD
- Picture Compression Format: JPEG
- Picture Enhancement: Flip photos, Rotate, Slideshow, Zoom

## Connectivity

- Rear Connections: Analog audio Multi-channel out, Composite video (CVBS) output, Digital coaxial out, Click-Fit Stereo Connectors, ComponentVideo out Progressive

## Convenience

- On-Screen Display languages: English, Hindi

## Power

- Power supply: 110-240V, 50/60 Hz
- Power consumption: <12 W

## Accessories

- Included accessories: 2 x AAA Batteries, Audio/Video cable, Remote Control, User Manual, World Wide Warranty leaflet

## Dimensions

- Packaging dimensions (W x H x D): 415 x 82 x 322 mm



Issue date 2011-06-20

Version: 1.0.3

12 NC: 8670 000 32721  
EAN: 87 12581 35454 1

© 2011 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)

\* Speakers suitable for this set: Stereo passive speakers, 10W rms/channel at 6 ohm at 10% THD