



Philips
Portable Radio

FM/MW
Analogue tuning
Battery operated



TAR1506

The pocket classic

Get out there with this ultra-portable FM/MW analogue radio. Easy tuning and clear sound keep you up to date with your favourite programmes. Whether you're doing gardening or going on a walking tour.

Traditional style

- Classic design. Easy to tune
- Analogue FM/MW radio
- Large traditional-style tuning window

The radio you love

- Simple controls. Thumbwheel for volume and on/off
- Headphone port for private listening

Take it anywhere

- Super portable. Ideal for home or away
- Battery operated (2 x AAA)
- Dimensions: 56 x 116.2 x 22 mm

PHILIPS

Specifications

Tuner/Reception/Transmission

- Tuner bands: FM, MW
- RDS: No

Sound

- Output power (RMS): 100 mW
- Sound System: Mono
- Volume control: rotary (analogue)

Loudspeakers

- Number of full-range drivers: 1
- Full-range driver diameter: 1.5"

Connectivity

- Audio/Video output: Headphone (3.5 mm)
- Audio in: No
- Bluetooth: No

Alarm

- No. of alarms: No
- Snooze (repeat alarm): No

Power

- Battery type: AAA size (LR3)

- Battery voltage: 1.5 V
- Number of batteries: 2

Accessories

- Included accessories: Quick start guide, Warranty certificate

Product dimensions

- Product dimensions (W x H x D):
5.6 x 11.62 x 2.2 cm
- Weight: 0.09 kg

Packaging dimensions

- EAN: 48 95229 11662 7
- Packaging dimensions (W x H x D):
8.5 x 15.62 x 3.73 cm
- Gross weight: 0.144 kg
- Net weight: 0.11 kg
- Tare weight: 0.034 kg
- Number of products included: 1
- Packaging type: Box
- Type of shelf placement: Hanging

Highlights

Classic design. Easy to tune

This super-portable analogue FM/MW radio is easy to tune on the go. Simply turn the side-mounted tuning wheel to slide the indicator along the scale. A large traditional-style tuning window makes it easy to see when you have reached the desired frequency.

Simple one-handed controls

One-handed operation is easy with this little radio. Volume and on/off are both controlled by a conveniently placed thumbwheel. There's a headphone port for private listening and a side-mounted switch to select FM or MW signals.

Super portable

Slip this radio into your pocket and take the news wherever you go. Or the game you just can't miss. Or the talk show you love. 2 x AAA batteries power the sound and a telescopic antenna ensures that you'll always get the best possible reception.



Issue date 2022-07-06

Version: 5.2.7

12 NC: 8670 001 73342
EAN: 48 95229 11662 7

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com