



Philips 5000 series  
Blu-ray Disc/ DVD player

3D Blu-ray Disc playback

Built-in WiFi  
DivX Plus HD  
Karaoke



**BDP5600K**

## Blu-ray 3D and the best of Internet on your TV

### experience Blu-ray 3D

Be amazed by the new dimension 3D Blu-ray brings to your movie experience at home. Enjoy the best of Internet on your TV, hassle-free with the speedy built-in WiFi-n. And playback more than ever before with DivX Plus HD.

#### See more

- Blu-ray 3D Disc playback for a full HD 3D experience at home
- DivX Plus HD Certified for high definition DivX playback

#### Hear more

- Dolby TrueHD and DTS-HD MA for HD 7.1 surround sound

#### Engage more

- Built-in WiFi-n for faster, wider wireless performance
- SimplyShare to connect & stream all entertainment wirelessly
- USB 2.0 plays video/music from USB flash/hard disk drive
- Turn your Smartphone into a remote for Philips AV products

#### Enjoy enhanced karaoke

- Karaoke for endless singing entertainment

# PHILIPS

# Highlights

## Blu-ray 3D Disc playback



Full HD 3D provides the illusion of depth for a heightened, realistic cinema viewing experience at home. Separate images for the left and right eyes are recorded in 1920 x 1080 full HD quality and alternately played on screen at a high speed. By watching these images through special glasses that are timed to open and close the left and right lenses in synchronization with the alternating images, the full-HD 3D viewing experience is created.

## DivX Plus HD Certified



DivX Plus HD on your Blu-ray player and/or DVD player offers the latest in DivX technology to let you enjoy HD videos and

movies from the Internet direct to your Philips HDTV or PC. DivX Plus HD supports the playback of DivX Plus content (H.264 HD video with high-quality AAC audio in an MKV file container) while also supporting previous versions of DivX video up to 1080p. DivX Plus HD for true HD digital video.

## SimplyShare



Philips SimplyShare lets you share your music, movies & photos from tablet, smartphone & PCs to your home theater & Blu-ray player. You can stream all entertainment directly from your DLNA-enabled devices or use remote control to access & stream media files from your PC. For the best wireless experience, install the SimplyShare app on your tablet/ smartphone. You are now ready to enjoy all your entertainment effortlessly.

## WiFi-n



WiFi-n, also known as IEEE 802.11n, is the new wireless network standard. It includes many new options to improve the quality of the wireless link, offering faster speed and wider range compared to previous WiFi standards. WiFi-n also features backward compatibility, which makes it possible for this player to transmit to and receive from routers that operate on older WiFi standards.

## USB 2.0

The Universal Serial Bus or USB is an industry standard that allows high-speed, easy connection of peripherals to PCs, consumer electronics and mobile products. The USB 2.0 provides better and faster performance - up to 40 times quicker than the USB 1.0 and with a data transfer rate of up to 480 Mbps from the original 12 Mbps. When plugged in, everything configures automatically. With USB 2.0, simply plug in your USB portable devices or hard disk drives, select the movie, music or photo and play away.



# Specifications

## Accessories

- Included accessories: 2 x AAA Batteries, Power cord, Product Registration Card, Quick start guide, Remote Control, User Manual

## Audio Playback

- Compression format: AAC, MP3, Ogg Vorbis, PCM, WAV, WMA

## Still Picture Playback

- Compression format: GIF, JPEG, JPEG HD, JPEG Progressive, PNG
- Picture Enhancement: Rotate, Slideshow with music playback, Zoom

## Video Playback

- BD Region Code: C
- DVD Region Code: 5
- Compression formats: DivX Plus™ HD, H.264, MPEG1, MPEG2, XviD, MPEG4 (AVC)
- Disc Playback Modes: A-B Repeat, Angle, Disc Menu, Pause, Repeat, Resume Playback from Stop, Search forward/reverse, Skip, Slow Forward, Standard Play, Zoom
- Video Enhancement: Deep Color, Progressive Scan, Video Upscaling, x.v. Color

## File Format

- Audio: aac, mka, mp3, wma
- Picture: GIF, JPEG, JPG
- Video: asf, avi, divx, flv, m2ts, mkv, mov, mp4, mpeg, mpg, wmv

## Optical Playback Media

- Playable Discs: AVCHD, BD, BD R / BD RE, CD, CDDA, CD-R/CD-RW, DVD, DVD +R/+RW, DVD -R/-RW, SVCD, VCD

## Karaoke Playback

- Standard functions: Echo level control, Mic volume control, Pitch control

## Connectivity

- Front Connections: USB 2.0
- Network connections: 802.11 b/g/n, Built-in WiFi
- Rear Connections: Composite video (CVBS) output, Digital coaxial out, Ethernet, HDMI output, USB 2.0, Analog audio Left/Right in
- Smart TV Plus: MyRemote App, SimplyShare

## Convenience

- BD-Live(1GB USB memory needed)
- Child Protection: Parental Control
- Ease of Use: Fast wake up, MyRemote app
- EasyLink (HDMI-CEC): One touch play, One touch standby, 21:9 format subtitle support, Remote

## Control-Passthrough

- Firmware upgradeable: Firmware upgradeable via USB, Online firmware upgrade
- On-Screen Display languages: Czech, Danish, Dutch, English, Finnish, French, German, Italian, Norwegian, Polish, Portuguese, Romanian, Russian, Slovak, Spanish, Swedish, Turkish, Greek, Hungarian

## Picture/Display

- Aspect ratio: 4:3, 16:9, 21:9
- D/A converter: 12Bit/148MHz
- Blu-ray 3D: Full HD 1080p
- Picture enhancement: High Def (720p, 1080i, 1080p), Progressive scan, Video upscaling

## Power

- Power consumption: 20 W
- Power supply: 50Hz, 220-240V
- Standby power consumption: 0.3 W

## Sound

- D/A converter: 24 bit, 192 kHz
- Dynamic Range (1kHz): =90 dB
- Frequency response: (20kHz) = |0.2|dB (Max./Min. 2ch, DVD) Hz Hz
- Signal to noise ratio: = 100 dB
- Sound Enhancement: Night Mode
- Sound System: Dolby Digital 5.1, Dolby Digital Plus, Dolby True HD, DTS Digital Surround, DTS-HD High Resolution Audio, DTS-HD Master Audio

## Outer Carton

- EAN: 87 12581 67754 1
- Gross weight: 1.66 kg
- Outer carton (L x W x H): 41.5 x 30 x 8.7 cm
- Nett weight: 1.26 kg
- Number of consumer packagings: 1
- Tare weight: 0.4 kg

## Packaging dimensions

- Packaging dimensions (W x H x D): 41.5 x 30 x 8.7 cm
- EAN: 87 12581 67754 1
- Gross weight: 1.66 kg
- Nett weight: 1.26 kg
- Number of products included: 1
- Packaging type: Carton
- Tare weight: 0.4 kg
- Type of shelf placement: Laying

## Product dimensions

- Product dimensions (W x H x D): 36 x 4.2 x 21.9 cm
- Weight: 1.09 kg



Issue date 2015-08-16

Version: 8.1.9

12 NC: 8670 001 00233  
EAN: 87 12581 67754 1

© 2015 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)