

Philips
5.1 Home theater

1000W RMS power
DVD playback

HTS3373



Spectacular surround sound with deep powerful bass

This full-digital system delivers outstanding surround sound, providing a theater-like movie experience in your home. It plays back a wide variety of formats from any sort of disc, and from portable media players and USB sticks.

Bring audio and video to life

- HDMI 1080p upscales to high definition for sharper pictures
- Advanced Class D Amplifier for compact, powerful sound

Connect and enjoy multiple sources

- Hi-Speed USB 2.0 Link plays video/music from USB flash drive

Easy to set up and use

- EasyLink to control all HDMI CEC devices via a single remote

Play all your movies and music

- DivX Ultra Certified for enhanced playback of DivX videos
- Plays WMV, DivX, WMA, MP3 and JPEG digital camera photos
- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW, DVD+R DL

Designed to enhance your living space

- Energy Star for energy efficiency and low power consumption

PHILIPS

Highlights

HDMI 1080p

HDMI 1080p upscaling delivers images that are crystal clear. Movies in standard definition can now be enjoyed in true high definition resolution - ensuring more details and more true-to-life pictures. Progressive Scan (represented by "p" in "1080p") eliminates the line structure prevalent on TV screens, again ensuring relentlessly sharp images. To top it off, HDMI makes a direct digital connection that can carry uncompressed digital HD video as well as digital multichannel audio, without conversions to analog - delivering perfect picture and sound quality, completely free from noise.

Hi-Speed USB 2.0 Link

The Universal Serial Bus or USB is a protocol standard that is conveniently used to link PCs, peripherals and consumer electronic equipment. Hi-Speed USB devices have a data transfer rate of up to 480 Mbps - up from the 12 Mbps in original USB ones. With Hi-Speed

USB 2.0 Link, all you have to do is plug in your USB device, select the movie, music or photo and play away.

EasyLink

EasyLink lets you control multiple devices like DVD players, Blu-ray players, TV's etc. with one remote. It uses HDMI CEC industry-standard protocol to share functionality between devices through the HDMI cable. With one touch of a button, you can operate all your connected HDMI CEC enabled equipment simultaneously. Functions like standby and play can now be carried out with absolute ease.

Plays it all

Play virtually any media format you want - whether they be WMV, DivX, MP3s or JPEGs. Experience the unbeatable convenience of great playability, and the luxury of sharing media files on your TV or home theater system - in the comfort of your living room.

Plays it all

Play virtually any disc you want - whether they be CDs, (S)VCDs, DVDs, DVD+R, DVD-R, DVD+RW, DVD-RW or DVD+R DL. Experience unbeatable flexibility and the convenience of playing all your discs on the one device.

DivX Ultra Certified

With DivX support, you are able to enjoy DivX encoded videos in the comfort of your living room. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, and DVD recordable discs. DivX Ultra combines DivX playback with great features like integrated subtitles, multiple audio languages, multiple tracks and menus into one convenient file format.



Specifications

Picture/Display

- D/A converter: 12 bit, 108 MHz
- Picture enhancement: High Def (720p, 1080i, 1080p), Progressive scan

Sound

- Total Power (RMS): 1000 W
- Output power (RMS): 6x167W
- D/A converter: 24 bit, 192 kHz
- Frequency response: 40-20000 Hz
- Signal to noise ratio: >60 dB
- Sound System: DTS, Dolby Digital, Dolby Prologic II, Stereo
- Sound Enhancement: Class "D" Digital Amplifier, Night Mode
- Equalizer settings: Rock, Action, Classic, Concert, Drama, Lounge, Gaming, Sports

Video Playback

- Compression formats: DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Ultra, MPEG1, MPEG2, WMV
- Playback Media: DVD-Video, CD-R/CD-RW, DVD+R/+RW, DVD-R/-RW, Video CD/SVCD
- Video disc playback system: NTSC, PAL

Audio Playback

- Compression format: MP3, WMA
- Playback Media: DVD+R/+RW, DVD-R/-RW
- MP3 bit rates: 32-256 kbps and VBR

Still Picture Playback

- Picture Compression Format: JPEG
- Playback Media: DVD+R/+RW, CD-R/RW, DVD-R/-RW, USB flash drive
- Picture Enhancement: Rotate, Zoom, Slideshow with music playback

Tuner/Reception/Transmission

- Tuner Bands: FM

Connectivity

- Front / Side connections: Hi-Speed USB, MP3 Line-in
- Rear Connections: HDMI output, Composite video (CVBS) output, AUX in, FM Antenna, Easy-Fit Speaker Connectors, Digital coaxial in, Digital optical in

Power

- Power supply: 120/230VAC, 50/60Hz
- Standby power consumption: < 1 W
- Power consumption: 180 W

Loudspeakers

- Satellite Speaker: 4 Floor standing pillars
- Satellite speaker drivers: 3" full range woofer

- Satellite speaker impedance: 4 ohm
- Satellite speaker freq range: 150-20000 Hz
- Center speaker drivers: 3" full range woofer
- Center freq range: 150-20000 Hz
- Center speaker impedance: 4 ohm
- Subwoofer driver: 6.5" high efficiency woofer
- Subwoofer freq range: 40-150 Hz
- Subwoofer impedance: 4 ohm
- Subwoofer type: Passive

Accessories

- Included accessories: Remote Control, 2 x AAA Batteries, CVBS video cable, FM antenna, Power cord, Quick start guide, User Manual, World Wide Warranty leaflet

Dimensions

- Set dimensions (W x H x D): 360 x 58 x 332 mm
- Set weight: 2.8 kg
- Surround Speaker dimensions (W x H x D): 262 x 1199 x 264 mm
- Surround speaker Weight: 3.376 kg
- Center speaker dimensions (W x H x D): 244 x 100 x 74 mm
- Center Speaker Weight: 0.849 kg
- Subwoofer dimensions (W x H x D): 163 x 363 x 369 mm
- Subwoofer Weight: 4.703 kg
- Packaging dimensions (W x H x D): 1030 x 307 x 425 mm
- Weight incl. Packaging: 21 kg

Outer Carton

- EAN: 87 12581 51139 5
- Gross weight: 27.8 kg
- Outer carton (L x W x H): 103 x 41.1 x 59.5 cm
- Nett weight: 23.2 kg
- Number of consumer packagings: 1
- Tare weight: 4.6 kg

Packaging dimensions

- Type of shelf placement: Laying
- Packaging dimensions (W x H x D): 103 x 59.5 x 41.1 cm
- EAN: 87 12581 51139 5
- Gross weight: 27.8 kg
- Nett weight: 23.2 kg
- Number of products included: 1
- Packaging type: Carton
- Tare weight: 4.6 kg

Product dimensions

- Cable length: 0 cm
- Product dimensions (W x H x D): 36 x 5.5 x 33.3 cm
- Weight: 3.11 kg



Issue date 2014-02-13

Version: 3.0.5

12 NC: 8670 000 57376
EAN: 87 12581 51139 5

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com