

Philips  
Cordless phone answer  
machine



TU7372

## A true 2 in 1 SMS phone

At the cutting edge of creative technology

The Zenia 300 offers the guarantee of having an exclusive product at home since not everyone can treat themselves to the most sophisticated design and most integral, extensive series of features.

### Multi-pack for ultimate convenience

- Use 2 handsets in separate rooms to transmit noises
- Conference call shares a conversation on several handsets
- Free intercom - Free internal calls between handsets

### Experience best sound quality

- Hands-free Duplex communication for a natural conversation
- Polyphonic ringtones for a more natural and realistic sound

### Maximize your messaging experience

- Text messaging (SMS) for short messages over a fixed line
- Eatoni predictive text entry simplifies writing SMS messages
- Create several SMS mail boxes that can be PIN-code protected

### Benefit from easy-to-use technology

- LCD screen with backlighting for convenience in the dark
- Fast forward message tracking and pause of messages
- Pilot key & carousel menu navigates in a menu-in-cycle form

# PHILIPS

# Highlights

## Baby-sit function

Worried about your baby not sleeping? No need to constantly go and check in his bedroom. The baby-sit mode allows you to keep an ear on him wherever you are in the house.

## Conference call function

Thanks to the conference call, there is no need to travel to meet people. Especially useful in a professional environment where several work stations are connected to the same base station, the conference call allows, for example, two colleagues from Paris to communicate with a colleague in China. A conference call allows two handsets to share the same external phone conversation in such a manner that each handset is able to communicate with the two others.

## Free intercom

No need to stop what you are doing and go to give the handset to your son when his friend calls: you can freely and easily call the handset in his bedroom and transfer the call.

## Full Duplex Handsfree

Full duplex handsfree use allows natural reproduction of a conversation in which both sides can speak and be heard at the same time, like in a natural conversation. Using full duplex technology, you can have a smooth and unbroken conversation with crystal clear sound and no echo for both parties.

## Polyphonic ringtones

A polyphonic ringtone means that the phone can play many tones simultaneously, so that an accurate musical performance is possible, and when played through the phone's speaker

these polyphonic ringtones sound like real music.

## Text messaging (SMS)

The Short Message Service (SMS) is a mechanism for delivery of short messages which can have up to 160 characters of text. These 160 characters are plain text in nature and can be comprised of words, numbers or an alphanumeric combination. The Eaton<sup>®</sup> LetterWise predictive text editor helps you to write text messages more quickly. With its unique SMS system you can receive up to 200 messages in 10 different mailboxes. Greeting to a loved one, a quick reminder about an important meeting, ...all this can now be put in a SMS and sent over the fixed network.

## Eatoni text editor

Eatoni's LetterWise is an easy-to-use text-entry solution requiring just 1.16 taps per correct letter. It makes typing on phone keypads as comfortable, fast, and accurate as using a typewriter keyboard. It is unique among predictive text entry solutions in its ability to easily handle the entry of abbreviations, names, addresses, and URLs.

## Personal mail boxes

Children at a certain age need some privacy at home when sending SMS to their friends. But paying for several mobile phones quickly gets very expensive. DECT phones provide up to 9 personal SMS mail boxes which can be protected by a PIN code - SMS can stay private despite collective phone usage. The user must tell his correspondents his mail box number so that they can send short messages directly to this personal mail box. Sending a SMS from a

personal mailbox makes it easy for the addressee to reply directly to this mailbox without having to remember the mailbox number.

## Backlight on screen

Backlighting is a feature that illuminates the LCD screen or keypad for use in the dark. The two most common types of backlighting include LED and electroluminescent (EL). Remotes backlit with LEDs are typically bright but uneven with a yellow or green color, while EL panels are smooth with blue, white or green shades.

## Fast forward and pause

No need to listen to entire messages of 5 minutes before getting the information you want. With the fast forward key you can skip all the bla bla and go directly to the part that interests you. The pause key allows you to stop at a certain point of the message, to write down a number, adress etc.

## Pilot key & carousel menu

The pilot key navigation system allows easy navigation and settings. The pilot key is a roller on the left side of the phone that can be scrolled up and down and pressed in the middle. It commands the Carousel menu which is a circular loop of menu icons displayed on the screen.

## Base and handset TAM control

Just look at the base station to know instantly whether you received messages. Listening or deleting messages then become as simple as pressing one key on the base station - for those who never remember where they left their handset.

# Specifications

## Picture/Display

- Backlight
- Backlight color: Blue
- Diagonal screen size - tele: 4.0 cm
- Display screen type: LCD TFT
- Color cabinet: Silver

## Sound

- Base station ringers: Instrumental, Polyphonic, Recordable melody
- Handset ringers: Instrumental
- Volume Control: digital, Volume Control rotary/encoder

## Convenience

- Auto out-of-range warning
- Base Station keys: Line, Call transfer, Volume control, Full dialing keypad, Last number redial, Local voice memo, Answering machine keys, Paging key
- Battery full indication
- Battery low indication
- Carousel Icons: Phonebook, Answerphone, Messages, SMS, Intercom, Network, Extra, Base, Handset, Call log
- Clock with calendar
- Drop proof: 120 cm
- Function: Do not disturb ringer mute, Cheapest rate function, Call cost, Alarm clock, Babysit function, Microphone mute, Chain dialling, Direct to Do Not Disturb mode, Short cut keys, Keypad lock, Free handset to handset call
- Handset Keys: Line, Pilot key, Cancel / Recall, Dialling keypad, Loudspeaker, Call log, Phonebook
- Hard Icons: Answerphone message, Battery level, In range / Out of range, Line / Internal call, Loudspeaker, Not locked, Silence, SMS
- Headphone jack
- Lines of text: 4
- Multi base capability: 4
- Multi handset capability: 8
- Text input: Eatoni
- Vibrator
- VIP group with own melody: 3
- Volume control

## Accessories

- Headset: Mono headset

## Green Specifications

- Eco Designed

- Halogen-free housing
- Packaging material: Carton
- Packaging type: Giftbox

## Dimensions

- Base dimensions: L\*H=140\*103\*60mm
- Base weight: 211 g
- Box dimensions (W x H x D): 420 x 122 x 190 mm
- Form Factor: Handset separate from base
- Handset dimensions: L\*H=121\*46\*30mm
- Handset weight: 114 g
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -25°C to 70°C
- Weight incl. Packaging: 1625 kg

## Power

- Ambient temperature: 5 °C to 40 °C
- Battery Type: NiMH
- Charging time: 12 hours hr
- Kind of Battery: Rechargeable
- Standby time: up to 250 hours
- Talk time: up to 16 hours

## Network Features

- Antenna: Fast Selection Technology, Integrated on base, Integrated on handset
- Compatible: GAP
- Dialing: Tone, Pulse

## Operator Requirements

- SMS
- Name and Caller ID
- Caller ID on call waiting
- Operators services phonebook

## Answering Machine

- Plug & Play Answering machine
- Recording time capacity: 55 min max
- Message counter on base
- Fast Forward message tracking
- Pause during message playback
- VIP outgoing message
- Call screening
- Answerphone remote access

## Memory Capacity

- Name & number shared phonebook: 255 names and numbers
- SMS storage capacity: 200 SMS
- Call log entries: 80 entries



Issue date 2018-01-18

Version: 1.0.2

12 NC: 9961 400 01621  
EAN: 87 10895 80099 0

© 2018 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)