



Philips 5000 Series  
Gaming Headset

**DTS Headphone:X 2.0**

2.4 G wireless + BT5.2 + 3.5 mm  
50 mm drivers/LED lighting  
Detachable unidirectional MIC



**TAG5106BK**

# Immerse Yourself In A Better Gaming Experience

Stylish design, 50 mm precise drivers and DTS surround sound, advanced 2.4 G and Bluetooth 5.2 dual wireless connection, and detachable unidirectional microphone provide great comfort and immersion during gameplay

## **Sound built for immersive gaming**

- 50 mm drivers, closed-back, tuned for gaming
- Detachable unidirectional noise-cancelling microphone
- DTS Headphone: X 2.0 technology features 7.1 surround sound
- Philips Precision Centre (P-Centre) software

## **Easy to reach, convenient to use**

- 2.4 G + BT5.2 + 3.5 mm ensure multi-platform compatibility
- Bluetooth 5.2 can connect many devices with Bluetooth
- 2.4 G wireless delivers dependable, lossless gaming audio
- Ultra-long battery life (more than 45 hours with LED off)

## **Comfortable fit, rich fun**

- Leatherette earpads with memory foam provide great comfort
- Adjustable head beam ensures a better fit
- Fascinating LED lighting creates more fun for gaming



# PHILIPS

## Gaming Headset

DTS Headphone:X 2.0 2.4 G wireless + BT5.2 + 3.5 mm, 50 mm drivers/LED lighting, Detachable unidirectional MIC

# Highlights

### 50 mm drivers, tuned for gaming



50 mm neodymium magnets drivers, with closed-back design, tuned by professional acoustic engineers, delivers a wide frequency range and rich accurate sound for gaming

### DTS Headphone: X 2.0



DTS Headphone: X 2.0 technology features 7.1 surround sound, the optimal spatial imaging for complete 360 degree immersion could help you survive and thrive in games.

### 2.4 G + BT5.2 + 3.5 mm



2.4 G and Bluetooth 5.2 dual wireless system, together with a 3.5 mm wired connection,

ensure multi-platform compatibility with PC, Mac, Xbox, PlayStation, Nintendo Switch and mobile devices

### Bluetooth 5.2



Bluetooth 5.2 can help you connect your gaming headset with many gaming devices integrated with Bluetooth technology, and you can answer calls or listen to music by streaming

### Fascinating LED lighting



Fascinating LED lighting creates more cooling atmosphere in your gaming world by providing RED, GREEN and BLUE colours, and Heartbeat LED lighting

TAG5106BK/00

### 2.4 G wireless connection



Professional-grade 2.4 G wireless technology delivers dependable, lossless audio with ultra-low latency for gaming

### Ultra-long battery life



Ultra-long battery life (more than 45 hours with LED lighting off) gives you continuous gaming sessions without any disruption

## Gaming Headset

DTS Headphone:X 2.0 2.4 G wireless + BT5.2 + 3.5 mm, 50 mm drivers/LED lighting, Detachable unidirectional MIC

TAG5106BK/00

# Specifications

### Sound

- Acoustic system: Closed
- Magnet type: Neodymium
- Impedance: 32 Ohm
- Speaker diameter: 50 mm
- Maximum power input: 20 mW
- Sensitivity: 101 dB
- Type: dynamic
- Frequency response: 20 - 20,000 Hz

### Connectivity

- Wireless connection: 2.4 G (via USB dongle), Bluetooth 5.2
- Wired connection: 3.5 mm

### Accessories

- 3.5 mm audio cable: 1.5 m
- Quick Start Guide

- USB charging cable: 0.6 m
- USB dongle: 2.4 G wireless

### Design

- Colour: Black
- Wearing style: Headband

### Product dimensions

- Product dimensions (W x H x D): 19 x 22.2 x 8.2 cm
- Weight: 0.375 kg

### Packaging dimensions

- Packaging type: Box
- Number of products included: 1
- Type of shelf placement: Hanging
- Packaging dimensions (W x H x D): 22.5 x 24.5 x 10.8 cm
- EAN: 48 95229 12700 5



Issue date 2023-08-19

Version: 9.2.2

12 NC: 8670 001 83634  
EAN: 48 95229 12700 5

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)