



Philips
Classic DVD micro system

• 50 W

MCD135

Obsessed with sound

Relax to great music and movies

Compact yet powerful, this system delivers incredible sound with 50 W RMS power. It also plays DVDs, music from USB and FM radio. Its compact design gives you extremely flexible placement, so you can enjoy superb sounds anywhere at home.

Enrich your movie experience

- Play DVD, DivX®, (S)VCD, MP3-CD, CD(RW) and Picture CD
- Dolby Digital for ultimate movie experience

Enrich your sound experience

- 2 x 25 W RMS/50 W Total Power
- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound

Enjoy your music from multiple sources

- Enjoy MP3/WMA music directly from your portable USB devices
- MP3 Link for portable music playback
- FM digital tuning with presets

PHILIPS

Highlights

Dolby Digital

Because Dolby Digital standards, the world's leading digital multi-channel audio standards, make use of the way the human ear naturally processes sound, you experience superb quality surround sound audio with realistic spatial cues.

2 x 25 W RMS/50 W Total Power

2 x 25 W RMS/50 W Total Power

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be

switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favourite music in the superior sound quality delivered by the audio system, the MP3 link is

also extremely convenient as all you have to do is to plug your portable MP3 player into the audio system.

USB Direct for MP3/WMA music



Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favourite moments with family and friends.



Specifications

Video Playback

- Playback Media: DVD+RW, DVD-Video, Picture CD, Video CD/SVCD, DivX Ultra
- Disc Playback Modes: Angle, Slow Motion, Zoom, A-B Repeat, PBC, Parental control
- DVD Region.: 2
- USB Direct Playback: JPEG

Audio Playback

- Playback Media: MP3-CD, CD-RW, CD-R, CD, WMA-CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/programme, Shuffle Play
- Loader Type: Top
- USB Direct Modes: Fast Reverse/Fast Forward, Play/Pause, Previous/Next, Repeat, Shuffle

Sound

- Output Power: 50 W RMS
- Sound Enhancement: Dynamic Bass Boost, Digital Sound Control 4 modes
- Sound System: Dolby Digital

Loudspeakers

- Main Speaker: Bass Reflex Speaker System, 4" woofer

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- Station presets: 10
- Tuner Enhancements: Auto Store

Connectivity

- Video Output - Analogue: Composite CVBS (yellow cinch), S-Video (on Hosiden), Component Y Pb Pr (cinch)
- Other connections: Line out, FM Antenna
- Headphones: 3.5 mm
- Audio Connections: 3.5 mm Line in

Convenience

- Alarms: Sleep timer, CD Alarm, Radio Alarm
- Clock: On main display
- Display Type: White FTD
- OSD Languages: English, Traditional Chinese, Portuguese, Spanish

Accessories

- Included accessories: Composite video cable (Y), FM/MW Antenna, Guarantee booklet, Quick Use Guide, 3.5 mm stereo line-in cable
- Remote control: 40-key with Lithium batteries

Power

- Power supply: 100-240 VAC, 50/60 Hz

Dimensions

- Set dimensions (W x H x D): 152 x 170 x 210 mm
- Main speaker dimensions (W x H x D): 152 x 170 x 210 mm
- Packaging dimensions (W x H x D): 535 x 265 x 252 mm
- Weight incl. Packaging: 3.52 kg



Issue date 2013-05-10

Version: 2.2.5

12 NC: 8670 000 66715
EAN: 87 12581 55883 3

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com

* Music with Digital Rights Management not supported.