

Philips  
DVD Micro Theater



MCD190

## DVD, VCD and MP3-CD playback

You're in touch with the latest and the coolest - now get a load of the hot 2-in-1 Micro Hi-Fi with DVD and MP3-CD playback! Relax to your fave movies and music. Home entertainment will never be the same again!

### **Enjoy your favorite movies, photos and music**

- Play DVD, (S)VCD, MP3-CD, CD(RW) and Picture CD
- Dolby Digital for ultimate movie experience

### **Enrich your sound experience**

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- Loudness for bass and treble enhancement
- 400W PMPO / 10W RMS total power

### **Wake up to CD or radio tunes**

- Wake up and sleep timer functions
- Digital tuning with 20 preset stations for extra convenience

# PHILIPS

# Highlights

## Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your

music by precisely adjusting the sound balance to match the type of music you are playing.

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be

switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## Loudness

In the sound spectrum, high and low frequencies are relatively less audible to human ears - especially at low volumes. By activating the Loudness feature, the bass and treble will be amplified so you can savor a more balanced sound perception overall.



# Specifications

## Sound

- Output Power: 2x5W RMS / 400W PMPO
- Sound Enhancement: Loudness, Digital Sound Control 4 modes, Dynamic Bass Boost
- Sound System: Dolby Digital

## Loudspeakers

- Main Speaker: 4" woofer, Bass Reflex Speaker System

## Video Playback

- Playback Media: DVD+RW, DVD-Video, Picture CD, Video CD/SVCD
- Disc Playback Modes: Angle, Slow Motion, Zoom, A-B Repeat, PBC, Parental control
- DVD Region.: 4

## Audio Playback

- Cassette Deck Technology: Mechanical
- Cassette Playback Modes: Electronic Speed Control
- Playback Media: MP3-CD, CD-RW, CD-R, CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- Loader Type: Top

## Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: CD Synchro Start Recording, Automatic Recording Level

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning
- Station presets: 20

## Connectivity

- Video Output - Analog: Composite CVBS (yellow cinch), S-Video (on Hosiden)
- Other connections: Active subwoofer Pre-out, Digital coaxial out, Line out, FM Antenna, MW Antenna
- Aux in: 1x(L/R)/ RCA
- Headphone: 3.5 mm

## Convenience

- Alarms: Sleep timer
- Clock: On main display
- Display Type: VFD display

## Accessories

- Included accessories: Composite video cable (Y), FM/MW Antenna
- Remote control: 45-key with 2xAA batteries

## Dimensions

- Set dimensions (W x H x D): 148 x 235 x 258 mm
- Main speaker dimensions (W x H x D): 142 x 235 x 212 mm
- Packaging dimensions (W x H x D): 342 x 312 x 446 mm
- Weight incl. Packaging: 8.43 kg



Issue date 2014-02-07

Version: 1.0.3

12 NC: 9073 100 13334  
EAN: 87 10895 96073 1

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)