



Philips  
Micro Music System

**Bluetooth®**

CD, MP3-CD, USB, DAB+, FM  
USB port for charging  
18W



**TAM3505**

## Classic looks. All of your music.

Step up your home listening with this classic-looking micro system. Easily stream music and podcasts, play CDs and tune in to crystal-clear digital DAB+/FM radio. You can connect laptops or other sources to it via USB or audio-in.

### Great sound for your music

- Classic design
- Bass-reflex loudspeakers. Richer low tones
- 3" woofer. 18 W maximum output power
- Digital Sound Control. Choose a preset sound style

### From CD classics to streaming

- All your music
- CD player. DAB+/FM radio with 20 presets. Audio-in
- USB port. Connect a legacy source or charge a mobile
- Bluetooth. Stream music, podcasts and more

### Fill the room with tunes

- At home in your home
- AC-powered. Remote control
- Main unit dimensions: 180 x 121 x 247 mm
- Speaker dimensions: 150 x 238 x 125 mm

**PHILIPS**

# Specifications

## Sound

- Maximum output power (RMS): 18W
- Sound enhancement: digital sound control, bass reflex speaker system
- Sound mode: Powerful, Clear, Bright, Warm, Balanced
- Volume control: rotary
- Frequency response: 66-20000 Hz
- Speaker impedance: 6 ohm

## Loudspeakers

- Number of sound channels: 2.0
- Driver configuration: Full range
- Number of full-range drivers: 2
- Full-range driver diameter: 3"

## Audio playback

- Playback media: CD, CD-R/RW, MP3-CD, USB flash drive
- Disc playback modes: fast forward/reverse, next/previous track search, repeat/shuffle/programme
- USB Direct playback modes: fast reverse/fast forward, play/pause, previous/next, repeat, shuffle, stop
- Audio supported formats: MP3
- Max sample rate: 24-bit/44.1 kHz

## Tuner/Reception/Transmission

- Tuner type: Digital
- Tuner bands: FM mono, FM stereo, DAB/DAB+
- Antenna: Detachable pigtail (75 ohm)
- Station presets: 10 (FM) + 10 (DAB)
- Tuner enhancement: auto digital tuning, auto scan, Easy set (plug and play)
- RDS: Yes.

## Connectivity

- Bluetooth profiles: A2DP, AVRCP, Multipoint (Multipair) support
- Bluetooth range: 10 M (free space)
- Bluetooth version: 4.2
- USB: USB host
- USB charging: 5 V, 1 A
- Audio in: 3.5 mm
- Smart Home: n.a.
- DLNA Standard: n.a.

## Convenience

- Clock: On main display, 24/12-hour display
- Display type: LED display
- Loader type: tray
- Alarms: Yes, Buzzer, DAB, FM, CD
- No. of alarms: 1
- Sleep timer
- Remote Control

## Design

- System components: Main control unit, Speakers
- Wall mountable: No

## Compatibility

- Smartphone/tablet APP control: No

## Power

- Power supply: 100-240 VAC, 50/60 Hz

## Accessories

- Included accessories: AC power cord, FM antenna, Remote Control, 2 x AAA Batteries, Quick start guide, Warranty Leaflet
- Power cord: Length: 1.5 m

## Dimensions

- Main Unit (W x H x D): 180 x 121 x 247 mm
- Main Unit Weight: 1.6 kg
- No. of speaker unit: 2
- Speaker Unit (W x H x D): 150 x 238 x 125 mm
- Speaker Weight (per Unit): 0.96 kg
- Set (W x H x D): 500x238x247 mm
- Set Weight: 3.59 kg

## Packaging dimensions

- EAN: 48 95229 10890 5
- Packaging dimensions (W x H x D): 57.7 x 31.2 x 18.5 cm
- Gross weight: 4.65 kg
- Net weight: 3.59 kg
- Tare weight: 1.06 kg
- Number of products included: 1
- Packaging type: Box
- Type of shelf placement: Standing

# Highlights

## All your music

This stylish micro system lets you stream playlists, play CDs and listen to DAB+ and FM radio. The digital radio tuner with 20 presets delivers crystal-clear reception and the CD player can read MP3 CDs and recorded CDs.

## Bass-reflex loudspeakers

Bookshelf-style loudspeakers give you clear sound and good bass from 3" woofers and bass-reflex ports. An 18 W maximum output brings decent sound to smaller spaces. Perfect for a home office or bedroom.

## Classic design

The two-tone central unit and speaker cabinets recall the design of hi-fi separates. The textured volume-control dial adds a satisfying analogue feel. There are buttons on the front of the unit for playback and source selection.

## Digital Sound Control

Hip-hop or choral, symphony or rock opera? Whatever you love, this micro system's Digital Sound Control function lets you enjoy it more. Pick from preset sound styles designed to bring out the best in your music.

## At home in your home

This AC-powered micro system looks great in any room. Bluetooth wireless range is 10 m and you can charge a smart device via the USB port. An easy-to-use remote puts key functions at your fingertips.



Issue date 2023-05-06

Version: 5.0.3

12 NC: 8670 001 67419  
EAN: 48 95229 10890 5

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)