

Philips Fidelio  
Over-ear wireless  
headphones

**Noise Cancellation Pro+**

Natural, balanced sound  
Leather premium design  
38 hours play time



L3

## Get inside the music. Anywhere.

What if you could always be in the perfect place to listen to the music you love?

Exquisitely tuned drivers, excellent Active Noise Canceling, and the right fit combine to create the perfect listening environment. Wherever you are.

**Detailed sound, no distractions**

- Philips Fidelio. Engineered for exceptional performance
- 40 mm drivers. Natural, balanced sound
- State-of-the-art hybrid Active Noise Canceling

**Seamless in every way**

- Touch controls. 38 hours play time (32 hours with ANC)\*
- Connect to any source. Wireless or wired
- IR sensor. Music pauses when you take the headphones off
- Philips Headphones app. Customize your experience
- One-touch pairing. Google Fast Pair\*

**Quality in every detail**

- Crafted for listening. Premium design
- Memory foam ear-cup cushions. Always a perfect fit
- Dual mics for crystal-clear calls. On-board voice control
- Sumptuous Muirhead leather. Responsibly sourced

# PHILIPS

# Highlights

## Philips Fidelio



From the sound to the materials, these over-ear closed-back wireless headphones are crafted to bring you deep into the music. No matter what size or shape your head is, the soft memory-foam ear-cup cushions fit closely, and the music pauses if you take the headphones off.

## Natural, balanced sound



The perfectly tuned drivers in these Hi-Res Audio certified headphones deliver beautifully balanced sound-whether ANC is turned on or off. Bass is tight and impactful without being overpowering. Midrange frequencies are full and smooth. High frequencies sparkle with detail.

## Hybrid Active Noise Canceling



Listen at the perfect volume-wherever you are. Adaptive noise canceling uses one external mic and one internal mic to filter out unwanted sounds, leaving you free to immerse.

Awareness Mode lets you bring the world back in when you need to.

## Crystal-clear calls



Two mics in each ear cup focus on the sound of your voice, dramatically reducing noise from the world around you. The fully integrated Google Assistant and Alexa are there to help you pull up your favorite playlists as soon as you ask.

## Touch controls



A full charge gives you more than a day of music, and a speedy 15-minute charge gives you 6 hours play time. There are touch controls for music and calls, and buttons for ANC on the ear cups, which also fold flat for easy storage.

## Crafted for listening



Lightweight aluminum and responsibly sourced Muirhead leather ensure these wireless headphones feel as premium as the sound. The

aluminum of the ear-cup rings is in matte dark satin, with embossed Philips Fidelio branding. The music pauses automatically when you take the headphones off.

## Philips Headphones app.




The Philips Headphones app lets you adjust the level of noise cancellation by switching between preset ANC modes. It also features a dedicated equalizer, and you can use the app to control the music you're streaming or access song information.

## Google Fast Pair\*



## Fast Pair

Google Fast Pair lets you pair your headphones to a compatible Android device with a single tap. When the headphones are placed near your Android device, you are automatically asked if you want to connect.



# Specifications

## Sound

- Frequency range: 7 - 40,000 Hz
- Speaker diameter: 40 mm
- Impedance: 16 Ohm
- Maximum power input: 20 mW
- Sensitivity: 103 dB (1k Hz)
- Driver type: Dynamic
- Hi-Res Audio

## Connectivity

- Bluetooth version: 5.1
- Wireless
- Bluetooth profiles: A2DP, AVRCP, HFP
- Detachable cable
- Maximum range: Up to 10 m
- Multipoint connection
- Supported codec: AAC, SBC, aptx, aptx-HD
- Type of wireless transmission: Bluetooth
- Headphone socket: 2.5 mm

## Outer Carton

- Length: 25.4 cm
- Number of consumer packagings: 3
- Width: 22.8 cm
- Gross weight: 3.655 kg
- Height: 26 cm
- GTIN: 1 48 95229 10839 1
- Nett weight: 1.161 kg
- Tare weight: 2.494 kg

## Convenience

- Automatic power off
- Volume control
- Philips Headphones app support
- Google fast pair
- Auto pause (IR sensor)
- Firmware updates possible
- Type of controls: Touch

## Power

- Rechargeable
- Number of batteries: 3 pcs
- Talk time: 38 hr
- Charging time: 2 hour(s)
- Music play time (ANC on): 32 hour(s)
- Music play time (ANC off): 38 hour(s)
- Fast charging time: 15 mins for 6 hrs
- Battery weight (Total): 10.1 g
- Battery capacity(Headphones): 800 mAh
- Battery type(Headphones): Lithium Polymer (built-in)

## Packaging dimensions

- Height: 21.67 cm
- Packaging type: Box
- Type of shelf placement: Hanging
- Width: 20.9 cm
- Depth: 7.69 cm
- Number of products included: 1
- EAN: 48 95229 10839 4
- Gross weight: 1.068 kg
- Nett weight: 0.387 kg
- Tare weight: 0.681 kg

## Product dimensions

- Height: 20.35 cm
- Width: 19 cm
- Depth: 5.15 cm
- Weight: 0.36 kg

## Accessories

- Others: 1 pcs hard carrying case
- Audio cable: 2.5-3.5mm stereo cable, L=1.2m
- Quick Start Guide
- Charging cable: USB-C cable, 500 mm
- Included adapters: Airplane adapter

## Design

- Color: Black
- Wearing style: Headband
- Foldable design: Flat
- Ear coupling material: Synthetic leather
- Ear fitting: Over-ear
- Earcup type: Closed-back

## Telecommunication

- Microphone for call: 2 mics
- ENC microphone

## UPC

- UPC: 8 40063 20164 4

## ANC features

- ANC technology: Hybrid, ANC Pro+
- Awareness mode
- Adaptive ANC
- Microphone for ANC: 4 mic
- ANC (Active Noise Canceling)

## Voice assistant

- Voice assistant compatible: Apple Siri, Google Assistant
- Voice assistant activation: Manual
- Voice assistant support



Issue date 2024-06-04

Version: 19.6.10

EAN: 48 95229 10839 4

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Google is a trademark of Google LLC. Google Fast Pair is not available in certain languages and countries.

\* Battery life of playtime is approximate and may vary depending on application condition.