

Philips Mini Hi-Fi System

FWC185

Rich Sound Experience

Set your sights on the attractive FWC185 Mini Hi-Fi System, which delivers superbly rich sound. You'll appreciate how easy it is to operate and control, just sit back, relax and enjoy your music all day, your way!

Enrich your sound experience

- Full range Bass Reflex Speaker System
- 2x15W RMS / 700W PMPO

Continuous enjoyment of your favorite music

- Stereo cassette deck
- AM/ FM tuner for radio enjoyment
- 3-disc changer for convenient multi-disc playback

Personalized sound settings

• Dynamic Bass Boost for deep and dramatic sound



Specifications

Sound

- Output Power: 2x15W rms / 700W PMPO
- Sound Enhancement: Bass Boost

Loudspeakers

• Main Speaker: 4" woofer, Full range, Bass Reflex Speaker System

Audio Playback

- Loader Type: 3 CD Carousel
- Number of Discs: 3
- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: 30-Track Programmable, Fast Forward/Backward, Next/Previous Track Search, Repeat/Shuffle/Program
- Cassette Deck Technology: Mechanical Number of decks: 1

Audio Recording

• Tape Recording Enhancement: CD Synchro Start Recording

Tuner/Reception/Transmission

• Tuner Bands: FM Stereo, MW, FM





Connectivity

· Headphone: 3.5 mm

Convenience

• Display Digits: 2

Accessories

- · Included accessories: User Manual, Remote Control
- Standard Package Includes: International Guarantee
- User Manual: English

Dimensions

- Set dimensions (W x H x D): 265 x 295 x 360 mm
- Main speaker dimensions (W x H x D): 175 x 295 x 175 mm
- Packaging dimensions (W x H x D): 409 x 370 x 523 mm
- Weight incl. Packaging: 10.4 kg

Power

• Power supply: 200-240 V, 50Hz

WC185/98

Highlights

Full range Bass Reflex Speaker

Bass Reflex Speakers delivers a deep bass experience. Differ from conventional loudspeakers, the addition of a bass pipe that is acoustically aligned to the woofer optimizes the low frequency roll-off. The result is a deep controlled bass and low distortion. Combined with the response of the woofer, it extends the overall low frequency sounds to create a whole new dimension of deep bass.

Stereo cassette deck

Stereo cassette deck

AM/ FM tuner

AM/ FM tuner for radio enjoyment

3-disc changer

With a three-disc changer for music playback, you can choose between three different CDs inside the device at any one time. This convenient feature allows you to savor a variety of music while saving you precious time from changing CDs frequently.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings from low to high - at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



© 2014 Koninklijke Philips N.V. Issue date 2014-02-10 All Rights reserved. Version: 3.0.10 Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners. 12 NC: 9073 100 13653 EAN: 87 10895 99320 3

www.philips.com