

Philips
Micro Hi-Fi System

MP3/WMA-CD playback

MCM9



Play MP3-CD & WMA-CD

in Sophisticated Style with Great Sound

Specifically designed for one who appreciates the ultimate in technology and style, this system exudes finesse and quality. Unleash the audiophile in you and savor the enhanced sounds from your MP3/WMA-CD through powerful, dynamic speakers.

Enrich your sound experience

- Ferro Fluid Cone Dome Tweeters
- Flat metal cone woofer
- 2-Way Bass Reflex Speaker System with detachable grilles
- 2x50W RMS and 2x100W music power

Longer listening, greater enjoyment

- 10 hours of MP3-CD or 20 hours of WMA-CD music

Personalized sound settings

- Incredible Surround™ for enhanced audio enjoyment
- Treble and Bass Control for easy high and low tone settings

Sounds great too

- Elegant wood-finished speakers

PHILIPS

Highlights

MP3-CD or WMA-CD playback

MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. A single CD can store up to 10 hrs of music. MP3 has become the standard audio compression format, allowing quick and easy audio file transfer. Windows Media Audio (WMA) is a highly compressed digital audio format from Microsoft that delivers great sound with music files that take up half the disk space and download in half the time. A single CD can store up to 20 hours of good quality WMA music recorded at a bit rate of 64 Kbps.

Incredible Surround™

Incredible Surround is an audio technology from Philips that dramatically magnifies the sound field to immerse you in the audio. Using state-of-the-art electronic phase shifting, Incredible Surround mixes sounds from left and right in such a way that it expands the virtual distance between the two speakers. This wider spread greatly enhances the stereo effect and creates a more natural sound dimension. Incredible Surround allows you to experience total surround with greater depth and width of sound, without the use of additional speakers.

Treble and Bass Control

Treble and bass are equalizer features that control the high and low frequency sound levels of your audio respectively. Treble specifically regulates the amplification of the high tones in the music while bass controls the amplification level of the low tones. Using the up and down keys, the listener can conveniently place more or less emphasis on the low and high tones, or leave treble and bass flat to playback music according to its original recorded setting. Treble and Bass Control lets you listen to your music the way you like it.



Specifications

Sound

- Output Power: 2x100 watts music power
- Sound Enhancement: Incredible Surround, Treble and Bass Control

Loudspeakers

- Main Speaker: 2 way, Bass Reflex Speaker System, 5.25" woofer, 2" tweeter, Speaker grilles detachable

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA
- Disc Playback Modes: 99-Track Programmable, Repeat/one/all/program, Shuffle Play
- Loader Type: Motorised, Tray
- ID3-tag support
- Cassette Deck Technology: Full Logical
- Cassette Playback Modes: Autoreverse, Electronic Speed Control, Full Auto Stop, Tape Counter

Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: Automatic Recording Level, CD Synchro Start Recording, One-Touch Recording

Tuner/Reception/Transmission

- Auto digital tuning
- RDS: Station Name, Program Type, Radio Text, RDS Clock Set, News

- Station presets: 40
- Tuner Bands: FM Stereo, MW
- Tuner Enhancements: Auto Store, Easy Set (Plug & Play)

Connectivity

- Aux in: Line in
- Headphone: 3.5 mm
- Other connections: FM Antenna, MW Antenna

Convenience

- Alarms: CD Alarm, Radio Alarm, Tape alarm, Snooze, Sleep timer
- Clock: On main display
- Display Type: White FTD
- Indications: DIM mode
- Eco Power Standby: 0.5 watt

Accessories

- Included accessories: AC Power Cord, FM/MW Antenna
- Remote control: 32-key with 2xAA Batteries

Dimensions

- Set dimensions (W x H x D): 175 x 252 x 350 mm
- Main speaker dimensions (W x H x D): 175 x 252 x 215 mm
- Packaging dimensions (W x H x D): 524 x 353 x 408 mm
- Weight incl. Packaging: 12.9 kg



Issue date 2014-02-07

Version: 3.0.6

12 NC: 9073 100 12264
EAN: 87 10895 86418 3

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com