



Philips  
DVD micro music system

**DVD, HDMI ARC**

CD, MP3-CD, USB, FM  
Karaoke  
100W max



**MCD5110**

# Relax with great music and movie

## Obsessed with sound

Bring on the best with this Philips DVD micro system—from DVDs, Divx movies and MP3-CDs. Powerful speakers with basspipes and high definition HDMI 1080p upscaling pump up your home entertainment experience.

### **Enrich your sound experience**

- 100W RMS total output power
- Bass Reflex Speakers deliver deep and powerful bass

### **Enjoy your favorite movies and music**

- HDMI 1080p upscales to high definition for sharper pictures
- HDMI ARC to access all the sound from your TV
- Play DVD, (S)VCD, MP3-CD, CD(RW) and Picture CD
- USB Direct for easy MP3 music playback
- Karaoke for endless singing entertainment at home

### **Easy to use**

- FM digital tuning to preset up to 20 stations

# PHILIPS

# Highlights

## HDMI 1080p



HDMI 1080p upscaling delivers images that are crystal clear. Movies in standard definition can now be enjoyed in true high definition resolution - ensuring more details and more true-to-life pictures. Progressive Scan (represented by "p" in "1080p") eliminates the line structure prevalent on TV screens, again ensuring relentlessly sharp images. To top it off, HDMI makes a direct digital connection that can carry uncompressed digital HD video as well as digital multichannel audio, without conversions to analog - delivering perfect picture and sound quality, completely free from noise.

## HDMI ARC

HDMI ARC to access all the sound from your TV

## USB Direct for easy MP3 music



Thanks to the complete file transferability, you can easily enjoy the convenience and fun of accessing more digital music via the built-in USB Direct.

## Karaoke for endless singing



Karaoke for endless singing entertainment at home

## Play DVD, VCD, MP3-CD, CD(RW) & Pict



The Philips player is compatible with most DVD and CD discs available in the market. DVD, (S)VCD, MP3-CD, CD(RW) and Picture CD - all of them can play on the player. SVCD stands for "Super VideoCD". The quality of a SVCD is much better than a VCD, especially much more sharpen picture than a VCD because of the higher resolution. CD(RW) is a shorthand term for a CD drive that can accept the common rewritable CD format.

## Bass Reflex Speakers

A chamber behind the speaker driver that channels air to acoustically tuned vents built into the speaker give the bass notes a more punchy, realistic sound.

# Specifications

## Sound

- Sound Enhancement: Digital Sound Control
- Sound System: Dolby Digital
- Maximum output power (RMS): 100W

## Loudspeakers

- Speaker drivers: 4.5" woofer
- Main Speaker: 2 way
- Loudspeaker types: Mylar tweeter

## Video Playback

- Playback Media: DivX, DVD-Video, Picture CD, Video CD/SVCD, DVD+R/+RW, DVD-R/-RW
- Disc Playback Modes: A-B Repeat, Angle, PBC, Slow Motion, Zoom, Parental control, Disc Menu, Fast Backward, Fast Forward, OSD, Resume Playback from Stop
- DVD Region.: 2
- Video Enhancement: Video Upscaling

## Audio Playback

- Playback Media: MP3-CD, CD, CD-R, CD-RW
- Disc Playback Modes: Repeat/one/all/program, Fast Forward/Backward, Next/Previous Track Search
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Stop

## Still Picture Playback

- Picture Compression Format: JPEG
- Picture Enhancement: Slideshow with MP3 playback
- Playback Media: Picture CD, CD-R/RW, DVD+R/+RW

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- Tuner Enhancements: Auto Store

- Station presets: 20
- Antenna: FM antenna
- RDS: Program Type, Station Name

## Connectivity

- HDMI 1: HDMI (Audio Return Channel)
- Video Output - Analog: Composite CVBS (yellow cinch)
- Audio Connections: Analogue Audio In (L/R)
- USB: USB host
- Microphone: Microphone socket
- Rear Connections: AUX in
- Subwoofer out: 1

## Convenience

- Alarms: CD Alarm, Sleep timer, Radio Alarm, USB alarm
- Clock: On main display
- Indications: DIM mode

## Accessories

- Included accessories: Composite video cable (Y), AC Power Cord
- User Manual: Multi-languages
- Remote control

## Dimensions

- Main unit depth: 243 mm
- Main unit height: 120 mm
- Main unit width: 200 mm
- Main speaker dimensions (W x D): 160 x 206 mm
- Main speaker height: 243 mm
- Packaging depth: 265 mm
- Packaging height: 465 mm
- Packaging width: 396 mm
- Net weight: 5.8 kg

## Power

- Power supply: 100-240VAC, 50/60Hz



Issue date 2016-12-14

Version: 2.0.8

12 NC: 8670 001 02474  
EAN: 87 12581 68574 4

© 2016 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)