



Philips
Surge protector

3 outlets
with Surge
2 USB

SPP1028A



Ideal for Travel

Power on the go

Three surge protected AC outlets and 2 USB charging outlets make this travel surge protector ideal for protecting and charging your mobile devices while on the go. Plug folds flat for neat and tidy storage. 612 Joules.

Plug more

- Converts 1 polarized outlet into 3
- 2 USB charging ports

Pure Protection

- \$100,000 connected equipment warranty*
- 612 Joules

Built-in convenience

- 3 outlets with protection
- USB Charging 2.1

Simplicity

- Worry free protection indicators

PHILIPS

Surge protector
3 outlets with Surge, 2 USB

Specifications

Product dimensions

- Product dimensions (W x H x D): 6 x 20 x 5.8 cm
- Product dimensions (W x H x D):
2.4 x 7.9 x 2.3 inch
- Weight: 0.5 kg
- Weight: 1.102 lb

Packaging dimensions

- Type of shelf placement: Laying
- Packaging dimensions (W x H x D): 6 x 20 x 5.8 cm
- Packaging dimensions (W x H x D):
2.4 x 7.9 x 2.3 inch
- Nett weight: 0.5 kg
- Nett weight: 1.102 lb
- Gross weight: 0.54 kg
- Gross weight: 1.190 lb
- Tare weight: 0.04 kg

- Tare weight: 0.088 lb
- UPC: 6 09585 22487 2
- Number of products included: 1
- Packaging type: Carton

Outer Carton

- Outer carton (L x W x H): 13.65 x 7.94 x 13.97 cm
- Outer carton (L x W x H): 5.4 x 3.1 x 5.5 inch
- Nett weight: 1.5 kg
- Nett weight: 3.307 lb
- Gross weight: 1.66 kg
- Gross weight: 3.660 lb
- Tare weight: 0.16 kg
- Tare weight: 0.353 lb
- GTIN: 1 06 09585 22487 9
- Number of consumer packagings: 3

SPP1028A/17

Highlights

\$100,000 equipment warranty

Protects your connected equipment for the life of the product.

2 USB charging ports

USB charging port allows you to charge USB devices

3 outlets with protection

Protects against surges/spikes through the AC lines by suppressing surge energy. The excess energy is clamped by the MOV when the unit is subjected to a surge event.

1 polarized outlet into 3

A multiple outlet adapter that converts 1 polarized outlet in to 3 polarized outlets by plugging directly into the wall

USB Charging 2.1

USB Charging ports rated at 2.1 amps enable you to charge your mobile devices-compatible with smart phones, iPOD, iPhone, and iPad

Protection indicators

LED lights let you know if your surge protector is functioning properly.

612 Joules

612 Joules



Issue date 2016-06-26

Version: 2.1.7

12 NC: 8670 000 88626
UPC: 6 09585 22487 2

© 2016 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com