



Philips
Uninterruptible power
supply

Battery back-up

8 outlets

SPB9180WA



45 min. runtime

Back up your computer system

This advanced battery back-up features s-OV technology to isolate, regulate and protect your connected equipment. Offering genuine surge protection, it is the only UPS with UL surge protection listing.

Ideal for computer workstations

- 1-line splitter
- Data line/phone protection
- Phone/data jack
- 6 ft USB cable
- Phone cord

Ultimate performance design

- 800VA, 400W
- s-OV technology
- Automatic Voltage Regulator (AVR)
- Auto shutdown software
- \$1,000,000 connected equipment warranty

Built-in convenience

- 6 ft power cord
- Audible alarm

PHILIPS
sense and simplicity

Uninterruptible power supply
Battery back-up 8 outlets

Specifications

Packaging

- Quantity: 1
- Gross Weight: 9.389 kg
- Tare Weight: .748 kg
- Net Weight: 8.641 kg
- Length: 53.3 cm
- Width: 18.4 cm
- Height: 26.0 cm

Outer Carton

- EAN/UPC/GTIN: 1 06 09585 13210 5
- Quantity: 2
- Gross Weight: 20.230 kg
- Tare Weight: .227 kg
- Net Weight: 20.003 kg
- Length (cm): 53.3 cm
- Width (cm): 19.7 cm
- Height (cm): 55.1 cm

SPB9180WA/17

Highlights

1-line splitter

These connectors route the telephone line through the surge protector and split the line to allow two devices to be connected. It offers the convenience of leaving two devices connected constantly even though they may not be used simultaneously

Data line/phone protection

These connectors accommodate either an RJ45 or an RJ11 cord. They route either line through the surge protector to guard against spikes and surges that may occur in the data or phone lines.

Phone/data jack

MOVs or sidactor are used for protecting the phone or network lines. They protect against surges/spikes through the phone or network lines.

800VA, 400W

This power rating advises how much total power you are able to back up without overloading the battery.

s-OV technology

This technology automatically senses an overvoltage and reacts quickly by completely disconnecting power from the main source, while continually delivering power to connected equipment from battery power. Power will be automatically reconnected to the main source once the surge event is over.

AVR

Provides consistently clean power. Adjusts power to the nominal level if the input power is a too high or low.

Auto shutdown software

Ensures that all open files are saved and computer shuts down safely without completely draining the battery

\$1,000,000 equipment warranty

Protects your connected equipment for the life of the product.

6 ft power cord

Provides power to the unit which can be 6 feet from the AC outlet.

6 ft USB cable

Connects computer to UPS so that power monitor and auto shutdown can be executed.

LED indicators

These LED indicators inform you of unit status at a glance

Phone cord

Allows you to connect a phone or fax machine



Issue date 2009-11-06

Version: 1.0.5

12 NC: 8670 000 29617
UPC: 6 09585 13210 8

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com