



Philips
CD Soundmachine

- VCD
- MP3-CD
- Tape

AZ5160

VCD/MP3-CD soundmachine

Enjoy your favorite VCD and MP3-CD in superb sound with this Philips CD soundmachine. Comes with powerful stereo speakers and dynamic bass boost, your handy system also includes cassette player and radio, so your music pleasure never ends.

Feature-packed VCD and CD player

- VCD2.0 playback
- MP3-CD playback means MP3 plays like a normal audio CD.
- FM/MW tuner for radio enjoyment
- Autostop cassette deck

Rich and clear sound

- Dynamic Bass Boost for deep and dramatic sound
- Bass Reflex Speaker System delivers a powerful, deeper bass
- Full range speakers for immersive and dynamic sound

Easy to use

- On Screen Display for easy navigation
- 9 frames digest preview for easy navigation
- Super Error Correction for distortion-free VCD playback
- PAL/NTSC compatible
- Handy remote control

PHILIPS

Specifications

Video Playback

- Playback media: video CD/SVCD
- Disc playback modes: A-B Repeat, fast backward, fast forward, introscan, OSD, pause, PBC, slow motion, Zoom

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD
- Disc playback modes: fast forward/backward, next/previous track search, repeat/shuffle/program
- Number of decks: 1
- Cassette deck technology: mechanical

Tuner/Reception/Transmission

- Tuner bands: FM, MW
- Antenna: FM antenna

Sound

- Sound enhancement: Dynamic Bass Boost
- Sound system: stereo
- Volume control: rotary (analogue)
- Output power: 2 x 1 W RMS

Loudspeakers

- No. of built-in speakers: 2
- Speaker grille finishing: metal

Audio recording

- Recording media: tape
- Tape recording enhancement: CD synchro start recording

Connectivity

- Audio/Video output: 3.5 mm video out, 3.5mm audio out

Convenience

- Display type: LCD display
- Display Digits: 3
- Loader type: top

Power

- Battery type: C size (LR14)
- Battery voltage: 1.5 V
- Number of batteries: 6
- Power type: AC Input

Accessories

- Remote control
- Cables/Connection: audio/video cable, power cord
- Others: User Manual
- Warranty: Warranty Certificate

Dimensions

- Gross weight: 3.2 kg
- Packaging depth: 262 mm
- Packaging height: 200 mm
- Packaging width: 377 mm
- Weight: 2.4 kg
- Main unit depth: 230 mm
- Main unit height: 159 mm
- Main unit width: 330 mm

Highlights

VCD2.0 playback

VCD2.0 playback

MP3-CD playback

MP3 stands for "MPEG 1 Audio layer-3". MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Bass Reflex Speaker System

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.



Issue date 2013-05-10

Version: 1.0.2

12 NC: 8670 000 33948
EAN: 87 12581 36395 6

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com