

Philips
DVD Home Theatre
System

DivX Ultra

HTS3115



HDMI™



Turn up your experience

with HDMI and USB

This stylish and compact full digital home entertainment system plays practically any disc in high quality Dolby, DTS multi-channel sound. So just relax and fully immerse yourself in movies and music at home.

Plays it all

- DivX Ultra Certified for enhanced playback of DivX videos
- Movies: DVD, DVD+R/RW, DVD-R/RW, (S)VCD, DivX
- USB Direct plays photos and music from USB flash drives
- Music: CD, MP3-CD, CD-R/RW & Windows Media™ Audio

Quick and easy set-up

- Full length tower speakers for more impressive sound

Great audio and video performance

- High definition JPEG playback for images in true resolution
- HDMI digital output for easy connection with only one cable
- Video Upscaling for improved resolution of up to 1080i
- DTS, Dolby Digital and Pro Logic II surround sound
- 12-bit/108MHz video processing for sharp, natural images

PHILIPS

sense and simplicity

Specifications

Picture/Display

- **D/A converter:** 12bit, 108MHz
- **Picture enhancement:** High Def (720p, 1080i)

Sound

- **D/A converter:** 24 bit, 96 kHz
- **Frequency response:** 30-20000 Hz
- **Signal to noise ratio:** > 65 dB
- **Sound System:** Dolby Digital, Dolby Prologic II, DTS, Stereo
- **Sound Enhancement:** Class "D" Digital Amplifier
- **Output power (RMS):** 4x75W + 2x100W
- **Total Sound Power (RMS):** 500 W

Video Playback

- **Playback Media:** CD-R/CD-RW, DVD-Video, Video CD/SVCD, DVD+R/+RW, DVD-R/-RW
- **Compression formats:** MPEG1, MPEG2, DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Ultra
- **Video disc playback system:** NTSC, PAL

Audio Playback

- **Playback Media:** CD, CD-R/RW
- **Compression format:** MP3, PCM, Windows Media™ Audio
- **MP3 bit rates:** 32-256 kbps and VBR

Loudspeakers

- **Satellite Speaker:** Magnetically shielded front
- **Satellite speaker freq range:** 120-20000 Hz
- **Satellite speaker impedance:** 8 ohm
- **Satellite speaker drivers:** 3" full range woofer
- **Centre Speaker:** Magnetically shielded
- **Centre freq range:** 120-20000 Hz
- **Centre speaker impedance:** 4 ohm
- **Centre speaker drivers:** 3" full range woofer
- **Subwoofer type:** Passive
- **Subwoofer freq range:** 30-120 Hz
- **Subwoofer impedance:** 4 ohm
- **Subwoofer driver:** 6.5" high efficiency woofer

Still Picture Playback

- **Playback Media:** DVD+R/+RW, CD-R/RW
- **Picture compression format:** JPEG

Tuner/Reception/Transmission

- **Tuner Bands:** FM Stereo, MW
- **Number of Preset Channels:** 40

Connectivity

- **Other connections:** Analogue audio Left/Right in, Easy-Fit speaker connectors, FM Antenna, MW Antenna, SCART I (CVBS, S-video/RGB out), HDMI out

Accessories

- **Included Accessories:** Batteries for remote control, FM/MW Antenna, Quick start guide, Remote Control, Scart Cable, User Manual, Warranty certificate

Power

- **Power supply:** 200-240 V, 50Hz
- **Standby power consumption:** < 1 W

Dimensions

- **Set dimensions (W x H x D):** 435 x 55 x 329 mm
- **Set weight:** 2.96 kg
- **Center speaker dimensions (W x H x D):** 239 x 99 x 69 mm
- **Centre Speaker Weight:** 0.72 kg
- **Subwoofer dimensions (W x H x D):** 193 x 265 x 339 mm
- **Subwoofer Weight:** 3.64 kg
- **Packaging dimensions (W x H x D):** 1194 x 436 x 412 mm
- **Weight incl. Packaging:** 21.4 kg
- **Front Speaker Width:** 249.8 mm
- **Front Speaker Height:** 1104 mm
- **Front Speaker Depth:** 249.8 mm
- **Front Speaker Weight:** 3.3 kg
- **Rear Speaker Width:** 100 mm
- **Rear Speaker Height:** 359 mm
- **Rear Speaker Depth:** 99 mm
- **Rear Speaker Weight:** 1.15 kg

Product highlights

High definition JPEG playback

With High Resolution JPEG playback, you can show up to 2 Megapixel resolution on your Flat TV (FTV). Now you can view your digital pictures in their true resolution, without loss of quality or details.

DivX Ultra Certified

DivX Ultra combines DivX playback with great features like integrated subtitles, multiple audio languages, multiple tracks and menus into one convenient file format.

Multi-format Movies with DivX

Multi-format playability allows you to play most disc formats for maximum disc compatibility and viewing pleasure.

USB Direct

Simply plug your device into the USB port on your Philips DVD system. Your digital music and photos will be played directly from the device. Now you can share your favourite moments with family and friends.

HDMI for simple AV connection

HDMI stands for High Definition Multimedia Interface. It is a direct digital connection that can carry digital HD video as well as digital multichannel audio. By eliminating the conversion to analogue signals it delivers perfect picture and sound quality, completely free from noise. HDMI is fully backward-compatible with (Digital Video Interface) DVI.

Video Upscaling up to 1080i

With Video Upscaling you can increase the resolution of SD (Standard Definition) video signals that DVD uses to HD (High Definition) so you'll be able to see more details thanks to a sharper, more true-to-life picture. The resulting HD video output signal can be fed to an HD display through HDMI (High-Definition Multimedia Interface).

DTS, DolbyDigital, ProLogic II

A built-in DTS and Dolby Digital decoder eliminates the need for an external decoder by processing all six channels of audio information to provide a surround sound experience and an astoundingly natural sense of ambience and dynamic realism. Dolby Pro Logic II provides five channels of surround processing from any stereo source.

12-bit/108MHz video DAC

12-bit Video DAC is a superior Digital-to-Analogue Converter that preserves every detail of the authentic picture quality. It shows subtle shades and smoother graduation of colours, resulting in a more vibrant and natural picture. The limitation of the usual 10bit DAC becomes particularly apparent while using large screens and projectors.

Music: Windows Media™ Audio

Multi-format playability allows you to play most disc formats for maximum disc compatibility and listening pleasure.

Full length tower speakers



Issue date 2009-02-03

Version: 1.0.3

12 NC: 8622 810 13671
EAN: 87 10895 97952 8

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com