

Philips
Micro music system

CD, MP3-CD, USB, FM
25W max

MCM2005



Relax to great music

with this compact music system

Listen to all your favorites on your portable music player with USB Direct and Audio in. This Philips MCM2005/12 Micro system also plays MP3-CD, WMA-CD and CD-R/RW, and features Bass Reflex speakers for powerful and dramatic bass.

Enrich your sound experience

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Digital Sound Control for optimized music style settings
- 25W RMS maximum output power

Enjoy your music from multiple sources

- Play MP3/WMA-CD, CD and CD-RW
- USB Direct for MP3/WMA music playback
- Audio-in for portable music playback

Easy to use

- Motorized CD loader for convenience access
- Digital tuning with preset stations for extra convenience
- Radio Data System for station information and data services

PHILIPS

Highlights

Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

USB Direct



With the USB Direct mode, simply plug in your USB device to the USB port on your Philips device and your digital music will be played directly from the Philips device.

Audio-in



The Audio in connectivity allows direct playback of Audio in content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the Audio in is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

Radio Data System (RDS)

The Radio Data System (RDS) lets you tune into radio stations without having to remember the frequencies. In standard mode, RDS displays the station name instead of the transmission frequency, facilitating quick and easy tuning. RDS also allows stations to send text messages such as news and station information directly to the radio display. Commonly used in Europe, RDS text is sent out on the same frequency the radio station broadcasts on. You can choose either the basic RDS display (station name) or subscribe to additional text-based services.



Specifications

Sound

- Maximum output power (RMS): 25W
- Sound enhancement: digital sound control

Loudspeakers

- Speaker drivers: 4" woofer
- Speaker types: bass reflex speaker system

Audio playback

- Disc playback modes: fast forward/backward, next/previous track search, repeat/shuffle/program
- Playback media: CD, CD-R/RW, MP3-CD, USB flash drive, WMA-CD
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, repeat, shuffle, stop
- Others: ID3-tag support

Tuner/Reception/Transmission

- Tuner bands: FM mono, FM stereo
- Station presets: 20
- RDS: program type, radio text, RDS clock set, station name
- Antenna: FM antenna (75 ohm)
- Tuner enhancement: auto digital tuning, auto scan, Easy set (plug & play)

Connectivity

- Headphone: 3.5 mm
- USB: USB host
- Audio in (3.5mm)

Convenience

- Alarms: CD Alarm, Radio Alarm, USB alarm
- Clock: On main display, sleep timer
- Display type: LCD display
- Loader type: tray

Accessories

- Included accessories: AC Power Cord, FM antenna
- Remote control: 31-key remote
- User Manual

Dimensions

- Main unit width: 200 mm
- Main unit height: 118 mm
- Main unit depth: 210 mm
- Main speaker dimensions (W x D): 140 x 144 mm
- Main speaker height: 224 mm
- Packaging width: 576 mm
- Packaging height: 274 mm
- Packaging depth: 190 mm
- Gross weight: 3.8 kg
- Net weight: 3.24 kg

Power

- Power supply: 220-240V, 50Hz



Issue date 2014-08-09

Version: 1.3.3

12 NC: 8670 001 05133
EAN: 08 71258 16934 80

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com