



wireless portable speaker

- Bluetooth
- Blue

BT150A/00

## Pool party. Shower party. Your party.

Wherever. Whenever. This waterproof Bluetooth speaker packs chunky bass into a tiny package and gives you surprisingly big sound. You get eight hours play time and audio-in. From the pool to the shower-make it your kind of party.

### Benefits

Turn it up. In the pool. In the shower.

- Waterproof to 1 m for up to 30 minutes. IPX7-rated
- 8 hours play time. USB charging. Micro USB cable included
- 1.5" full-range speaker. A passive radiator boosts bass
- Anti-clipping function. Play it loud without distortion

Music or calls

- Built-in mic. Take your calls via the speaker
- Audio-in. Connect to almost any source

### Features

Waterproof and ready to go

Poolside, lakeside, in the shower. This waterproof IPX7-rated speaker floats and can withstand being submerged in depths of up to 1 m for up to 30 minutes.

- Up to 10 m wireless range

Bring the tunes. Anywhere.

- Buttons on speaker for play and volume/skip tracks
- Finely knitted detachable carry strap
- Hang it from your bag, or on your bike. 9.5x9.5x3.8 cm
- LED lights around the speaker grille. Blue/random colors

8 hrs play time. USB charging.

The battery gives you 8 hours play time from a full charge. Charging takes around 3 hours, and is easy via the included micro USB cable.

# PHILIPS

Control your music

Control the music from buttons on the side of the speaker. Press for play and double-press the volume up/down buttons to skip tracks. The speaker grille has LED lights that glow a steady blue, or flash random colors.

Crisp sound. Punchy bass.

The 1.5" full-range speaker delivers crisp, clear sound even when you play it loud. A passive radiator boosts the bass giving you that much more punch on the low-end tones.

Built-in mic

Power on the speaker and it's ready to pair with your Bluetooth device. The wireless range is 10 m and the built-in mic lets you take calls out loud. When a call comes in, the music pauses automatically.

Audio-in for easy connection

Want to connect to an external audio source like a turntable or MP3 player? The audio-in socket at the back of the speaker lets you connect to almost any electronic device.

Specifications

[field not found 'disclaimer\_text']

Accessories

Included accessories	Quick install guide World Wide Warranty leaflet carrying strap
Cable	USB charging cable

Power

Battery type	lithium polymer (built-in)
Operating time on battery	up to 10 hr

Sound

Output power (RMS)	4W
Sound System	Mono

Connectivity

Bluetooth profiles	A2DP AVRCP HFP
Bluetooth range	Line of sight, 10M or 30FT
Audio in (3.5mm)	Yes
Bluetooth version	4.2

Compatibility

other Bluetooth-enabled device work with	Yes  up to iOS 10.2, Bluetooth 4.2 or below
--	---

Convenience

Display type	LED display (multi-color)
Water resistance	IPX7

Design and finishing

Color	Blue
-------	------

Dimensions

Packaging dimensions (WxDxH)	11.5 x 5 x 15 cm
Product weight	0.21 kg
Weight incl. Packaging	0.3 kg
Product dimensions (WxDxH)	9.5 x 9.5 x 3.95 cm



data subject to change  
2023, June 19  
Version: 2.0.3  
EAN: 6951613997284

© 2023 Koninklijke Philips N.V.  
All rights reserved.  
  
Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.  
  
[www.philips.com](http://www.philips.com)