



Philips
Digital PhotoFrame

26.4cm/10.4"

16:9 frame ratio

SPF4610



"...couldn't stop laughing that day!"

Keep your most memorable moments alive year round with Philips Photoframe. This compact frame is easy to use and looks good in any home environment.

Top quality display for amazing viewing experience

- imagen Pro for sharp, vibrant and natural skin colors
- Add new glow to old memories with RadiantColor

Simple intuitive operation and great convenience

- Keep time with fun clocks
- Automatic slideshow from memory card
- Quick easy menu for browsing, searching, and organizing

Green design

- Our packaging are small to minimize materials used
- Auto on/off display at pre-set times for power saving

PHILIPS
sense and simplicity

Specifications

Picture/Display

- Viewing angle: @ C/R > 10, 130° (H) / 110° (V), 120° (H) / 100° (V)
- Lifetime, to 50% brightness: 20000 hr
- Aspect ratio: 16:9
- Panel resolution: 1024 x 600
- Brightness: 160 cd/m²
- Contrast ratio (typical): 500:1
- Effective viewing area: 1024x600

Storage Media

- Built-in memory capacity: 128MB (for 1000 photos)
- Memory Card Types: Secure Digital (SD), Secure Digital (SDHC), Multimedia Card, Memory Stick, Memory Stick Pro

Convenience

- Photo format supported: JPEG photo
- Card Reader: Built-in (1x)
- Placement: Landscape, Portrait
- Buttons and controls: 3 buttons
- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Regulatory approvals: CE, GOST

Accessories

- Included accessories: AC-DC Adapter
- User Manual: Dutch, English, French, German, Italian

Dimensions

- Set dimensions with stand (W x H x D): 286.5 x 189.5 x 122 mm
- Weight: 0.58 kg
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -10°C to 60°C

Power

- Power supply: 100-240VAC, 50/60Hz
- Power consumption: 3 W
- Power mode supported: AC powered
- DC output Ampère: 0.65 A
- DC output Volt: 5 V

Packaging dimensions

- Type of shelf placement: Dummy
- EAN: 87 12581 60336 6
- Number of products included: 1
- Packaging dimensions (W x H x D): 33,5 x 26,5 x 6,5 cm
- Gross weight: 0,873 kg
- Nett weight: 0,553 kg
- Tare weight: 0,320 kg
- Packaging type: Dummy

Outer Carton

- GTIN: 1 87 12581 60336 3
- Number of consumer packagings: 3
- Gross weight: 2,891 kg
- Outer carton (L x W x H): 34,5 x 20,6 x 28 cm
- Nett weight: 1,659 kg
- Tare weight: 1,232 kg

Highlights

Our packaging are small

We make our packaging as small as possible to minimize materials used in production as well as fuel during transportation.

Keep time with fun clocks

Switch to the clock mode when you don't need to view photos. Instantly, your PhotoFrame become a clock.

Automatic slideshow start up

Slideshow of photos starts automatically once you insert the memory card.

imagen Pro for vibrant colors

The unique Philips imagen enhancement technology automatically analyzes your photos to correct color and adjust for optimal contrast. imagen Pro is a more advanced image enhancement which includes the 3 essential elements from imagen to have more color accuracy, color depth and smart contrast. On top of these, imagen Pro offers enhanced skin color, sharper images and flicker-free photo viewing which is very important for still pictures.

RadiantColor

RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the color on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.



Issue date 2013-04-04

Version: 2.1.4

12 NC: 8670 000 76416
EAN: 87 12581 60336 6

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com