

Philips
Digital PhotoFrame

- 20.3cm (8")
- 4:3 frame ratio

SPF1528



Our best holiday ever!

The stylish Philips Digital photo frame SPF1528 plays both photos and videos. Now you can relive those priceless moments in full glory - with vibrant color, motion and sound.

Top quality display for amazing viewing experience

- imagen Pro for sharp, vibrant and natural skin colors
- Add new glow to old memories with RadiantColor

Simple intuitive operation and great convenience

- Supports photos, videos and music
- Keep time with fun clocks
- Automatic slideshow from memory card
- Quick easy menu for browsing, searching, and organizing

Green design

- Our packaging are small to minimize materials used
- Auto on/off display at pre-set times for power saving

PHILIPS

Specifications

Picture/Display

- Viewing angle: @ C/R > 10, 120° (H) / 100° (V)
- Lifetime, to 50% brightness: 20000 hr
- Aspect ratio: 4:3
- Panel resolution: 800 x 600
- Brightness: 160 cd/m²
- Contrast ratio (typical): 500:1

Storage Media

- Built-in memory (RAM): 2GB (for 3000 photos)
- Memory Card Types: Secure Digital (SD), Secure Digital (SDHC), Multimedia Card, Memory Stick, Memory Stick Pro

Convenience

- Photo format supported: JPEG photo
- Card Reader: Built-in (1x)
- Placement: Landscape, Portrait
- Buttons and controls: 4-way navigation key and enter, Power button
- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Video format supported: in .MOV and .AVI format, MotionJPEG, MPEG4 AVC/H.264

Power

- Power supply: 100-240VAC, 50/60Hz
- Power mode supported: AC powered
- DC output Ampère: 1 A
- DC output Volt: 9 V

Connectivity

- USB: USB 2.0 Master

Accessories

- User Manual: English
- Included accessories: AC-DC Adapter, Quick start guide

Dimensions

- Set dimensions with stand (W x H x D): 225 x 184.5 x 34 mm
- Weight: 0.58 kg
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -10°C to 60°C

Packaging dimensions

- EAN: 87 12581 61653 3
- Number of products included: 1
- Packaging type: Carton
- Packaging dimensions (W x H x D): 25 x 21 x 9.5 cm
- Gross weight: 0.8 kg
- Nett weight: 0.55 kg
- Tare weight: 0.25 kg

Outer Carton

- GTIN: 1 87 12581 61653 0
- Number of consumer packagings: 2
- Gross weight: 1.8 kg
- Outer carton (L x W x H): 26 x 20.5 x 22.2 cm
- Nett weight: 1.1 kg
- Tare weight: 0.7 kg

Highlights

Keep time with fun clocks

Switch to the clock mode when you don't need to view photos. Instantly, your PhotoFrame become a clock.

Automatic slideshow start up

Slideshow of photos starts automatically once you insert the memory card.

RadiantColor

RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the color on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.

Supports multimedia

Supports photos, videos and music to allow you freedom to share memories through different ways.



Issue date 2013-08-18

Version: 1.0.4

12 NC: 8670 000 80488
EAN: 87 12581 61653 3

© 2013 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com