

Philips  
Multimedia Speaker 5.1

MMS460



## Stunning sound

PC5.1 speakers

### Experience true multimedia

- Easy to connect to either a PC or a laptop
- 5.1 channel sound for Dolby Digital® and EAX® reproduction

### Hear every detail

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Subwoofer for deep bass plus satellites for clear highs
- Digital Dynamic Bass Boost for optimized bass at any volume

# PHILIPS

# Highlights

## 5.1 channel playback

5.1 channel sound for reproduction of Dolby Digital® and EAX® sound sources

## Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and

lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

## Digital Dynamic Bass Boost



Digital Dynamic Bass Boost is an intelligent bass booster that delivers maximum bass enhancement at high volumes without sound distortion and at low volumes without

compromising on bottom-end bass frequencies. Technologically advanced electronics constantly monitor volume and bass levels, precisely calibrating both to prevent sound distortion, thus producing optimized bass. Digital Dynamic Bass Boost enables the enjoyment of superb bass performance - regardless of the chosen volume level.

## For PC or Laptop

Can be connected to either a PC or a laptop

## Subwoofer + satellite speakers

The audio system is separated into a subwoofer that is optimized to reproduce bass frequencies and satellite speakers that are optimised for mid- and high-range frequencies. The result is a system that powerfully reproduces the full range of audio frequencies from deep bass to crystal clear high notes with the minimum of distortion.



# Specifications

## Sound

- Bass enhancement: Digital Bass Boost
- Volume Control: Analogue Volume Control
- Wires: Fixed Wires

## Loudspeakers

- Loudspeaker Enhancement: Magnetic Shielded LSB

## Convenience

- Power on indication

## Power

- Power LED indicator: Blue

## Accessories

- Included accessories: Quick install guide



Issue date 2024-04-13

Version: 3.0.4

UPC: 0 37849 95174 3

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)