



Philips Streamium
Wireless Music
Center&Station

Streamium

WACS7500

Free your music

Enjoy all your music in every room - wirelessly

Rip and store all your music on the sleek Philips Streamium Wireless Music System WACS7500's 80 GB HDD and stream tunes to different rooms throughout your home. There's also colourful Album Art and Internet Radio to enhance your enjoyment.

All your music on one wireless system

- Wireless streaming between Center, Station(s) and PC
- 80GB hard disk to store and playback up to 1500CDs
- CD and USB Direct playback
- Enjoy Internet Radio

Easy navigation and control

- Easy and intuitive user interface with album art display
- My Room, My Music: Listen to different music in each room
- Music Broadcast: Listen to the same music on all stations
- Music Follows Me: take your music with you from room to room

Quality sound performance

- 80W RMS/Center, 30W RMS/Station with Super Sound Panel

Expandable

- Extend your system by adding up to 5 Wi-Fi Stations

PHILIPS
sense and simplicity

Specifications

Sound

- Equalizer settings: Classic, Jazz, Pop, Rock, Techno, Neutral
- Sound Enhancement: Dynamic Bass Boost 3 steps, Equalizer, Incredible Surround, Treble and Bass Control, Class "D" Digital Amplifier, Smart equalizer
- Music Power: 160 W
- Volume Control: Volume Control up/down
- Output power (RMS): 2 x 20W + 40W

Loudspeakers

- Built-in speakers: 2
- Loudspeaker types: Super Sound Panel, Integrated subwoofer, Non-detachable

Audio Playback

- Compression format: MP3, WMA, PCM, non DRM AAC (m4A)
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: Next/Previous Track Search, Repeat/Shuffle/Program, Fast Forward/Backward
- ID3-tag support
- Loader Type: Slot
- MP3 bit rates: 8-320 kbps and VBR
- WMA bit rates: up to 192kbps, CBR/VBR
- Hard Disk Playback Mode: Album, Genre, Playlist, All tracks, Same Artist, Same Genre, Uncompressed tracks
- Hard Disk Streaming Mode: Wi-Fi streaming to 5 stations, "My Room, My Music", "Music Follows Me", "Music Broadcast"
- PC Link playback mode: MP3 streaming via network, Wi-Fi wireless connection
- Sample frequencies: 8-48 kHz (MP3)
- USB Direct Modes: Play/Pause, Previous/Next, Stop

Audio Recording

- Recording Media: HDD
- Recording speed: 1 x, 4 x
- Audio file format: MP3

Storage Media

- Hard Disk Capacity: 80 GB

Tuner/Reception/Transmission

- Tuner Bands: FM

- Auto digital tuning
- Auto store
- Number of Preset Channels: 50

Connectivity

- Audio cinch in: Analog AUX (Center/Station)
- Audio cinch out: Analog Line-out (Center)
- Headphone: 3.5 mm
- Antenna: FM Dipole
- Wireless connections: Wireless LAN(802.11g)
- Power: 220 - 240 V 50 Hz
- Wireless Universal Plug & Play: Enabled
- LAN wired: Ethernet (RJ 45) 1x

Convenience

- Display Type: LCD
- Backlight
- Backlight color: White
- On-Screen Display languages: English, Dutch, French, German, Italian, Spanish
- Digital Content Management: WADM software included
- Eco Power Standby: 1 watt
- Headphone jack
- Wall mountable / Ceiling Throw: Wall Mountable - Station
- Clock: On main display

Accessories

- Cables: Ethernet Cable
- CD-ROM: Installation CD-ROM, WADM and utilities softwares.
- Remote control: 2-way 6-line Display, 1-way Remote
- Batteries: 4 x AAA + 2 x AA
- Warranty Card: Warranty Card
- Included accessories: FM antenna
- Quick start guide: English, Spanish, Brazilian Portuguese
- User Manual: English, Spanish, Brazilian Portuguese

Dimensions

- Master carton weight: 18.5 kg
- Product dimensions (WxDxH): 614mm x 172mm x 272mm
- Set weight: 8.83 kg
- Carton dimensions (WxDxH): 700mm x 380mm x 370mm

Highlights

Wireless Streaming with PC

Using a Wi-Fi network, enjoy your favorite songs as they continuously stream from your PC's music library to the Streamium Wireless music center or to the station(s), or from the Streamium center directly to the station(s). Whether your audio collection is stored on the Streamium or on your PC, you can fill your entire home with the same song or play a different track in each room; the choice is yours. There are no wires, no cables and no hassles. Enjoy the freedom of listening to all your audio anywhere you want in your home.

Enjoy Internet Radio

Internet radio is an audio broadcasting service that is transmitted via the Internet. One of the most popular formats is MP3. Some internet stations are affiliated with a 'terrestrial' radio station or network while others are internet-only radio stations, which are independent and devote their broadcasts only to the World Wide Web. With Internet Radio, you can enjoy access to online radio stations from anywhere in the world and listen to a wide variety of genres; get news, sports and entertainment updates, or connect to favorite or niche stations from Austria to Yugoslavia.

My Room, My Music

With My Room, My Music, each member of your family can select and play their favorite music from the stored collections in the Streamium Wireless music center. Multiple User Access technology simultaneously streams music selected from the Streamium center to the station. One Streamium can stream music to up to five Stations, giving you six different music options for the whole family to enjoy in any room - simultaneously and instantly.

Music Broadcast to Stations

Be your own DJ at your home party and simultaneously broadcast your favorite dance music from the Wireless Music Center to all Wireless Music Stations installed in various parts of your home. Great for parties!

Music Follows Me

Music follows Me feature allows you to bring your favorite music from room to room in your house without having to restart navigation and playback of that particular track. By simply pressing a button, your favorite song will follow you anywhere you go in your house.



My room my music



Music follows me



Music broadcast



InternetRadio



UPnP



WiFi CERTIFIED



Issue date 2013-02-01

Version: 2.0.6

12 NC: 8670 000 34426
EAN: 87 12581 36841 8© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com

* Actual free memory may be less due to device pre-configuration
* Some features require broadband internet access support