



Philips  
DVD player with USB

DivX Ultra

DVP5166KX



## Enjoy full DivX interactivity

with 5.1 channel output

Does size matter? Ever heard of less is more? Introducing the best value DVD player. No complications! Just a simple set that plays practically any disc format, including your digital photos with absolutely no compromise to picture quality.

### Bring audio and video to life

- 12-bit/108MHz video processing for sharp and natural images
- Smart Sound optimizes audio settings
- 192kHz/24 bit audio DAC enhances analogue sound input
- Progressive Scan component video for optimized image quality
- 5.1 channel audio output for surround sound

### Play all your movies and music

- DivX Ultra Certified for enhanced playback of DivX videos
- Plays DivX, MP3, WMA and JPEG digital camera photos
- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW

### Easy to use

- USB Direct plays photos and music from USB flash drives

### Enjoy enhanced karaoke

- Karaoke Scoring for fun and exciting song contests at home

# PHILIPS

# Highlights

## DivX Ultra Certified

With DivX support, you are able to enjoy DivX encoded videos in the comfort of your living room. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, and DVD recordable discs. DivX Ultra combines DivX playback with great features like integrated subtitles, multiple audio languages, multiple tracks and menus into one convenient file format.

## Plays it all

Play virtually any media format you want - whether they be DivX, MP3s, WMA or JPEGs. Experience the unbeatable convenience of great playability, and the luxury of sharing media files on your TV or home theater system - in the comfort of your living room.

## 192kHz/24 bit audio DAC

192kHz sampling enables you to have an accurate representation of the original sound curves. Together with a 24-bit resolution, more information is captured from the original analogue sound wave form, giving a much richer audio reproduction.

## Karaoke Scoring

Add a dash of fun to your Karaoke sessions with Karaoke Scoring. Allow your performance to be judged for further improvement, or for friendly competitions. Karaoke Scoring automatically rates your singing and gives you a humorous picture that is tied to how well you did. The fun never ends.

## Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably

sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

## 5.1 channel audio output

5.1 channel audio output for surround sound

## USB Direct

Simply plug your device into the USB port on your Philips DVD system. Your digital music and photos will be played directly from the device. Now you can share your favorite moments with family and friends.



# Specifications

## Picture/Display

- D/A converter: 12 bit, 108 MHz
- Picture enhancement: Progressive scan, Video upsampling, Smart Picture

## Sound

- D/A converter: 24 bit, 192 kHz
- Frequency response: 30-20000 Hz
- Signal to noise ratio: 90
- Distortion and Noise (1kHz): 65 dB
- Crosstalk (1kHz): 70 dB
- Dynamic Range (1kHz): 80 dB
- Sound System: Dolby Digital

## Video Playback

- Playback Media: CD, CD-R/CD-RW, Video CD/SVCD, DVD, DVD+R/+RW, DVD-R/-RW, DivX, DVD-Video
- Compression formats: MPEG1, MPEG2, DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Ultra
- Video disc playback system: PAL, NTSC

## Audio Playback

- Playback Media: CD, MP3-CD, MP3-DVD, WMA-CD, CD-R/RW, Audio CD
- Compression format: PCM, MP3, Dolby Digital, DTS, WMA
- MP3 bit rates: 32 - 320 kbps

## Still Picture Playback

- Playback Media: DVD+R/+RW, DVD-R/-RW, CD-R/RW, Picture CD, Kodak Picture CD
- Picture Compression Format: JPEG
- Picture Enhancement: Flip photos, Rotate, Zoom,

Slideshow with MP3 playback

## Connectivity

- Front / Side connections: Microphone, USB
- Rear Connections: Composite video (CVBS) output, Digital coaxial out, ComponentVideo out Progressive, Analog audio Multi-channel out

## Convenience

- Child Protection: Child Lock, Parental Control
- On-Screen Display languages: English, Polish, Russian
- Karaoke: MIC volume

## Power

- Power supply: 230V, 50Hz
- Power consumption: < 10 W
- Standby power consumption: < 0.8 W

## Accessories

- Included accessories: Audio/Video cable, Quick start guide, World Wide Warranty leaflet, Remote Control, 2 x AAA Batteries, User Manual, Power cord

## Dimensions

- Set dimensions (W x H x D): 435 x 38 x 209 mm
- Packaging dimensions (W x H x D): 490 x 82 x 296 mm

## Multimedia Applications

- Multimedia connections: USB memory class device
- Playback Formats: DivX, JPEG Still pictures, MP3



Issue date 2014-02-10

Version: 1.0.4

12 NC: 8670 000 37483  
EAN: 87 12581 39943 6

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)