

PHILIPS

Headphones with
mic

14.8-mm drivers/open-back

Ear bud

SHE3015TL



Extra bass

Soft body for comfy fit

Philips SHE3015 headphones with jelly body earbuds offer a soft, comfortable fit. Available in eye-catching colours. The built-in mic and control make hands-free talking on mobile easy.

Enjoy quality sound

- 14.8-mm (0.6") speaker drivers for high quality sound
- Neodymium magnets enhance bass performance and sensitivity

Ultimate wearing comfort

- Rubberised front caps for wearing comfort
- Soft body ensures a comfortable fit

Design for convenience

- Flexi-Grip design for durability
- Built-in microphone switches you from music to phone calls

Highlights

14.8-mm (0.6") speakers

Large 14.8-mm (0.6") speaker drivers squeezed into earbud headphones deliver high quality sound.

Built-in microphone

The built-in microphone lets you switch from listening to music to taking phone calls - easily, so you'll always stay connected with what matters most to you.

Flexi-Grip

A soft, flexible part protects the cable connection from damage that otherwise would occur due to repeated bending.

Neodymium magnets

Neodymium is the best material for producing a strong magnetic field for greater sensitivity in a voice coil, better bass response and higher overall sound quality.

Rubberised front cap

A rubberised front cap provide a totally soft body for wearing comfort.

Soft body

The transparent, rubberised headphone body moulds itself to the shape of the ear for comfortable listening.

Specifications

Sound

Acoustic system: open
Frequency response: 9 - 22 000 Hz
Diaphragm: PET
Magnet type: Neodymium
Type: Dynamic
Voice coil: copper
Speaker diameter: 14.8 mm
Sensitivity: 107 dB
Maximum power input: 25 mW
Impedance: 16 ohm

Connectivity

Type of cable: copper
Cable Connection: two-parallel, symmetric
Finishing of connector: nickel plated
Cable length: 1 m
Connector: 3.5 mm

Outer Carton

Length: 34,5 cm
Number of consumer packages: 24
Width: 19,7 cm
Gross weight: 1,2586 kg
Height: 16,3 cm
GTIN: 1 69 23410 73227 3
Net weight: 0,3216 kg
Tare weight: 0,9370 kg

Inner Carton

Length: 17,9 cm
Number of consumer packages: 3
Width: 8 cm
Height: 6 cm
Net weight: 0,0402 kg
Gross weight: 0,1287 kg
Tare weight: 0,0885 kg
GTIN: 2 69 23410 73227 0

Packaging dimensions

Height: 17,5 cm
Packaging type: Soother
Type of shelf placement: Soother
Width: 5,2 cm
Depth: 2,8 cm
Number of products included: 1
EAN: 69 23410 73227 6
Gross weight: 0,0339 kg
Net weight: 0,0134 kg
Tare weight: 0,0205 kg

Product dimensions

Height: 2,1 cm
Width: 1,6 cm
Depth: 1,25 cm
Weight: 0,0134 kg

Design

Colour: Teal

