

Philips
Micro Hi-Fi System

Compact design

MCM285



Obsessed with sound

Relax with great music

Enjoy rich sound with the Philips micro hi-fi system. Playback your favorite portable music using the USB Direct or MP3 link. Digital Sound Control optimizes your music style settings. Stylishly designed with high quality speakers.

Unlimited listening pleasure

- MP3 Link for portable music playback
- Play MP3/WMA-CD, CD and CD-RW

Enrich your sound experience

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 25W RMS total power output

Start the day your way

- Wake up and sleep timer functions
- Digital tuning with 40 preset stations for extra convenience

Refined in sound and look

- Easy-to-use remote control included

PHILIPS

Specifications

Sound

- Sound enhancement: digital sound control 4 modes, Dynamic Bass Boost
- Output power: 25 W RMS

Loudspeakers

- Speaker drivers: 4" woofer
- Speaker types: bass reflex speaker system

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: repeat/shuffle/program

Tuner/Reception/Transmission

- Tuner bands: FM stereo, MW
- Station presets: 40
- Antenna: FM antenna
- Tuner enhancement: auto digital tuning, auto scan

Connectivity

- Audio/Video output: Headphone (3.5mm)
- MP3 Link: 3.5mm stereo line in

Convenience

- Alarms: CD alarm, radio alarm

- Clock: on main display, sleep timer
- Loader type: top
- Display type: LCD display

Accessories

- Cables/Connection: *Flat pin adaptor, 3.5 mm stereo line in cable
- User Manual: Spanish, B-Portuguese
- Remote control
- Others: FM antenna, Quick start guide
- Warranty: World Wide Guarantee booklet

Dimensions

- Gross weight: 5.9 kg
- Main speaker dimensions (W x D): 146 x 185 mm
- Main speaker height: 236 mm
- Main unit depth: 239 mm
- Packaging depth: 275 mm
- Main unit height: 236 mm
- Packaging height: 340 mm
- Main unit width: 146 mm
- Packaging width: 397 mm

Power

- Power supply: 50/60 Hz
- Power supply: 110 - 240 V



Highlights

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

MP3 Link

The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.



Issue date 2016-10-05

Version: 3.0.5

12 NC: 8670 000 38242
EAN: 87 12581 40514 4

© 2016 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Avoid extensive use of the set in a volume higher than 85 decibel
because this may damage your hearing.