

Philips
Micro Hi-Fi System

- MP3/WMA-CD playback
- USB Direct

MCM277



Unique wall-mountable design

with USB Direct playback

Trendy and progressive, unique innovation and style appeals to you. And so will the vividly chic MCM277 with dynamic sound performance packed in a sleek design with MP3/WMA-CD and USB Direct playback that can also be wall mounted.

Unlimited listening pleasure

- Enjoy MP3/WMA music directly from your portable USB devices
- Play MP3/WMA-CD, CD and CD-RW
- Convenient line-in jack for portable music playback

Enrich your sound experience

- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 2 x 5 W RMS/2 x 10 W music power/400 W PMPO

Start the day your way

- Wake-up and sleep timer functions
- Digital tuning with 40 pre-set stations for extra convenience

Watch your disc spin

- Front motorised CD door with viewing window
- Wall-mountable option for flexible placement

Highlights

USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favourite moments with family and friends.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses

graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of

the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Specifications

Sound

- Output power (RMS): 2 x 5 W
- Output Power: 2 x 10 Watts music power
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost

Loudspeakers

- Main Speaker: Bass Reflex Speaker System, 4" woofer

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: 40-Track Programmable, Repeat/one/all/programme, Shuffle Play
- Loader Type: Front, Motorised
- ID3-tag support
- USB Direct Modes: Fast Reverse/Fast Forward, Play/Pause, Previous/Next, Programme Play, Repeat, Shuffle, Stop

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning
- Station presets: 40
- Tuner Enhancements: Auto Store
- RDS: Programme Type, Station Name, Radio Text, RDS Clock Set

Connectivity

- Headphones: 3.5 mm

- Other connections: FM Antenna, MW Antenna
- USB: USB host
- Audio Connections: 3.5 mm Line in

Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer, USB alarm
- Clock: On main display
- Display Type: LCD
- Backlight colour: White
- Eco Power Standby: 1 watt

Accessories

- Included accessories: FM/MW Antenna, Screws for wall mounting x 2, World Wide Warranty leaflet
- Remote control: 24-key with battery
- User Manual: English
- Quick start guide: English

Dimensions

- Set dimensions (W x H x D): 194 x 269 x 90 mm
- Main speaker dimensions (W x H x D): 160 x 269 x 90 mm
- Packaging dimensions (W x H x D): 310 x 314 x 238 mm
- Weight incl. Packaging: 5.5 kg

Power

- Power supply: 220-240 V, 50 Hz



Issue date 2013-05-10

Version: 1.0.5

12 NC: 8670 000 39625
EAN: 87 12581 42167 0

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com