

Philips
Micro Hi-Fi System

MP3/WMA-CD playback

USB Direct

MCM700



Pure sound in a refined design

with USB Direct playback

Satisfy all your audio needs with the stylish and compact MCM700 Micro Hi-Fi System featuring USB Direct playback. Admire the mirror-finished center unit while you revel in high quality sound delivered from the chic wood-finished speakers.

Unlimited listening pleasure

- Enjoy MP3/WMA music directly from your portable USB devices
- Play MP3/WMA-CD, CD and CD-RW

Enrich your sound experience

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- Loudness for bass and treble enhancement
- 2x80W RMS/2x160W music power

Design that blends into your interior(s)

- Elegant wood-finished speakers
- High-end component design

PHILIPS
sense and simplicity

Highlights

Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Loudness for bass and treble

In the sound spectrum, high and low frequencies are relatively less audible to human ears - especially at low volumes. By activating the Loudness feature, the bass and treble will

be amplified so you can savor a more balanced sound perception overall.

USB Direct for MP3/WMA music



Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

High-end component design

The component-designed micro system comes with a stand that features four triangular feet. It can prevent any audio frequency distortion due to vibration, overheating and electromagnetic interference generated from the amplifier and CD loader. The result is smooth and excellent sound reproduction.



Specifications

Sound

- Output Power: 2x80W RMS, 2x160W Music Power
- Sound Enhancement: Loudness, Digital Sound Control 4 modes, Dynamic Bass Boost

Loudspeakers

- Main Speaker: 2 way, 4" woofer, Bass Reflex Speaker System, Speaker grilles detachable, Piezo tweeter

Audio Playback

- Playback Media: WMA-CD, MP3-CD, CD-RW, CD-R, CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- Loader Type: Motorised, Top
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Shuffle, Stop

Tuner/Reception/Transmission

- Auto digital tuning
- Station presets: 40
- Tuner Bands: FM Stereo
- RDS: Radio Text, RDS Clock Set, Station Name
- Tuner Enhancements: Auto Store

Connectivity

- Other connections: FM Antenna

- Aux in: 2x(L/R)/ RCA
- Headphone: 3.5 mm
- USB: USB host

Convenience

- Alarms: CD Alarm, Sleep timer, Radio Alarm, USB alarm
- Clock: On main display
- Display Type: VFD display
- Eco Power Standby: 1 watt
- Indications: DIM mode

Accessories

- Included Accessories: FM antenna, World Wide Warranty leaflet
- Remote control: 24-key with Lithium batteries
- Quick start guide: English, German, Dutch, French, Spanish, Italian
- User Manual: 16 languages

Dimensions

- Set dimensions (W x H x D): 208 x 156 x 268 mm
- Main speaker dimensions (W x H x D): 145 x 230 x 215 mm
- Packaging dimensions (W x H x D): 475 x 275 x 330 mm
- Weight incl. Packaging: 10.35 kg

Power

- Power supply: 220-240V, 50Hz



Issue date 2009-07-17

Version: 3.0.6

12 NC: 9073 100 13532
EAN: 87 10895 98245 0

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com