## User Manual Addendum

## 1. Notes on charging the built-in lithium battery

Please note that your device contains built-in lithium batteries. The charging capacity of lithium batteries will decrease over time due to their self-discharge characteristics. To ensure the longevity of your device's battery, we recommend charging the built-in lithium battery to around 50% every 6 months when the device is not in use.

## 2. Bluetooth pairing

Note: This product with Play-Fi CAP version 506.3.0.063 or 506.3.0.077 requires Play-fi/Wi-fi connection to be set up and functioning before

Bluetooth pairing is allowed to operate. Please follow the instructions in the section "Connect to Wi-Fi (Wireless Operation)" in user manual to complete Play-fi/Wi-fi setup when the product is used for the first time.

## Bluetooth pairing procedure:

- 1. Switch the device to Bluetooth source.
- Press Source button → on remote control for more than 3 sec. Or Press setting menu → to select BT PAIR and press > to start.
- 3. Find the device with name XXXXX-BT in available device list in yourphone/tablet (XXXXX is the name chosen during Play-Fi setup).
- 4. Select XXXXX-BT and wait for Bluetooth connection to be made. Normally, complete in 1-2 seconds.