



Philips Showline
Media center

Showline

MCP9350I

Enter a world of entertainment from your sofa

Anywhere in your home

A powerful media center giving you TV, internet, music, video, photo & much more in the comfort of your livingroom or anywhere in your home.

Add a new dimension to your viewing

- Digital Natural Motion for smooth moving images
- Motion Adaptive De-interlacing for razor sharp images
- High Definition playback

Great convenience

- Dual tuner: Record channel 1 while watchng channel 2
- Direct access to central stored video, music & photos
- LikeMusic - your personal DJ to match music to your mood

Designed for your living room

- Horizontal design styled for your TV
- Easy to connect to your TV and Home Theater system
- Intuitive user interface lights up selected device keys only

Access your online favorites

- Video & Music on demand
- Additional functionality through future software upgrades

PHILIPS

Specifications

Picture/Display

- Digital Natural Motion: Digital Natural Motion
- Operating system: MS Windows XP MCE
- Picture enhancement: Motion adaptive de-interlacing

Video Playback

- Playback Media: CD, CD-R/CD-RW, DVD, DVD+R, DVD+R DL, DVD+R/+RW, DVD+RW, DVD-R, DVD-R DL, DVD-R/-RW

Video Recording

- Recording Media: DVD+R DL, DVD+R/+RW, DVD-R DL, DVD-R/-RW, CD-R/RW

Storage Media

- Hard Disk Capacity: 250 GB

Multimedia Applications

- Memory Card Types: Compact Flash type I, Compact Flash type II, Memory Stick, Memory Stick Pro, Microdrive, MultiMedia Card (MMC), Secure Digital Card (SD), Smart Media Card
- Multimedia connections: 8-in-1 Memory Card Reader

Tuner/Reception/Transmission

- Number of TV tuners: 2
- TV system: PAL, SECAM

Connectivity

- Front / Side connections: Headphone Out, i.LINK DV in (IEEE1394, 4-pin), Microphone, USB 2.0 2x
- LAN wired: Ethernet (RJ 45) 1x
- LAN wireless: Wireless LAN (IEEE802.11g)
- Rear Connections: Analog audio Left/Right in 2x, Analog audio Left/Right out 2x, Antenna IEC75, Digital coaxial out, Digital optical out, DVI-D, FM Antenna, S-Video out, VGA out, S-Video in 2x, CVBS in 2x, USB 2.0 2x, IEEE 1394 6 pins 2x,

Telephone line in, IR Blaster 2x

Convenience

- Electronic Program Guide: Microsoft EPG
- Keyboard accessory: Wireless
- Remote Control: Universal
- Remote control: Sofa
- Remote control type: RC4370

Accessories

- Included accessories: AC Power Cord, Audio Cable, Batteries for remote control, Coax digital audio cable, Ethernet cable, FM antenna, Full SCART cable, HDMI-DVI adapter cable, IFU / User Manual, Quick start guide, S-Video cable, Universal Remote Control, World Wide Warranty leaflet, DVI-D to DVI-D cable, IR Blaster 2x, TV RF signal splitter, SCART to Y/C, CVBS, L/R, Wireless Keyboard with batt.
- Remote Control 12NC: 312814713132

Software

- Philips Media Manager: UPnP multimedia content server

System Requirements

- Processor: 3.0 GHz P4 HT
- RAM memory: 512 MB

Dimensions

- Packaging dimensions (WxHxD): 590 x 487 x 232
- Product dimensions (WxDxH): 430 x 392 x 100
- Product weight: 9.42 kg
- Weight incl. Packaging: 13.42 kg

Power

- Power consumption: 130 W
- Power supply: 100-240VAC, 50/60Hz
- Standby power consumption: 5.2

Highlights

Digital Natural Motion

Philips invented Digital Natural Motion to eliminate juddering effects that are visible with moving picture content. Digital Natural Motion estimates motion in the picture and corrects juddering movements in both broadcast and recorded movie material (such as DVD). The resulting smooth motion reproduction and excellent sharpness take the viewing experience to a higher level.

Motion adaptive de-interlacing

This smart de-interlacing algorithm is able to detect the type of video source (such as Still Picture, Motion Picture or Film) and automatically optimize the de-interlacing process with Spatial, Temporal or Film mode de-interlacing. The result is that it delivers razor sharp and stable images every time.

High Definition playback

High Definition playback

Dual tuner

Dual tuner: Record channel 1 while watching channel 2

Direct access to content

Direct access to central stored video, music & photos

LikeMusic

LikeMusic is your smart and intuitive personal DJ which matches your music to your mood. By pressing the LikeMusic button, a short playlist of songs - similar to the song style you're listening to - is generated. This is all achieved by Philips patented algorithm which analyzes music for tempo, voice gender and instrumentation. A meta-tag is added to the song file so when you hit the LikeMusic button, a search is performed based on the meta-tag. To keep you in the same mood, the most similar songs are added to a playlist and playback begins once the original song ends.

Horizontal design

Horizontal design styled for your TV

Easy to connect

Easy to connect to your TV and Home Theater system

Intuitive user interface

Only the relevant keys for the currently selected device are backlit for extra operational convenience.

Video & Music on demand

Video & Music on demand

Future proof

To keep your device up to date and enhance its functionality you can download new softwares that become available. Connect the device to the Internet, either directly or through a PC, and launch the upgrade utility.



Issue date 2014-02-07

Version: 3.0.5

12 NC: 8622 810 12704
EAN: 87 10895 90776 7

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com