

CD Soundmachine

AZ2538

# Remote Control MP3 Music from Your PC

Uniquely designed with dual orientation, set it vertically or horizontally to fit any space, the AZ2538 is only for the savvy and wired. With USB PC Link to free your PC music and Gameport for total game immersion, you're in for an awesome entertainment experience.

## MP3 music at your fingertips

- USB PC Link for direct MP3 streaming
- Song title display for easy navigation
- MP3-CD playback

## Connect to great games and excitement

- Gameport connection to your game console
- Sound mode presets to maximize your gaming pleasure

## Powerful bass you can hear and feel

- MAX Sound technology
- Bass Reflex Speaker System
- 8W total power

## Unique design for any space

- Fits vertically or horizontally to enhance any space

EXPANUM

CERTIFIED **USB**



# PHILIPS

## Technical specifications

### Sound

- Output Power (RMS): 2 x 4W
- Sound system: Stereo
- Sound enhancement technology: Max Sound technology
- Equalizer: 3-bands
- Spectrum analyser: VU meter
- Volume control: Rotary

### Loudspeakers

- Main speaker: 2 x 4"
- Loudspeaker enhancements: Bass Reflex System

### Audio Playback

- CD player: MP3-CD/CD-R/RW compatible
- CD loader type: Toploader with manual door
- CD player enhancements: 20 track CD programmable, Shuffle play, Repeat one/all, CD next/previous track search
- MP3-CD player enhancements: Support mixed mode MP3 file, Support UDF
- PC link

### Audio Capturing

- Audio file format: MP3

### Tuner / Reception

- Tuning technology: Digital
- Station presets: 30
- Antenna: Telescopic antenna for FM reception, Internal antenna for AM reception
- Turner bands: FM stereo, AM

### Connectivity

- PC link: USB1.1
- Gameport
- Headphone: 1 x 3.5 mm
- AC socket

### Convenience

- Display: 7-Digit LCD
- Backlight: Amber

### Accessories

- Remote control: 21 Keys (RC19621011)
- Cables: Main cord, AV cables, USB cable
- CD-ROM
- Stand

### Software

- MusicMatch Jukebox

### Power

- AC/DC operation
- Battery type: 8 x 1.5V, R20

### Dimensions

- Packaging type: D-box
- Product dimensions (WxHxD): 20 x 7 x 11.3 Inch
- Product weight: 9.3 lbs
- Package dimensions (WxHxD): 22 x 10.8 x 13.7 Inch
- Weight incl packaging: 14.8 lbs



## Product highlights

### USB PC Link

USB PC Link lets you playback your MP3 music through the powerful speakers of Philips sound systems instead of your PC speakers. By connecting a PC directly to your audio system with a USB cable, you can stream MP3 music directly to your sound system, transforming your PC into a 'massive MP3 music jukebox'. The control buttons on the sound system and remote control provide easy navigation and control of the MP3 music stored in the MusicMatch Playlist. You can also view song title information as well as elapsed play time on the sound system's display.

### MP3-CD Playback

The MP3-CD format combines the advantages of MP3 digital audio compression with the affordable and widely accepted CD storage format. The end result is that a tiny 8cm MP3-CD can hold over 3 hours of MP3 music, while a normal 12cm disc can hold over 10 hours. Using readily available software, you can rip music from your audio CDs or download MP3 music legally from the internet and burn it to a recordable or rewritable 12cm or 8cm CD. The resulting MP3-CD can be played back as though it were a normal audio CD.

### Gameport

Gameport is an easy connection solution that links your game console directly to your audio system for enhanced gaming sound quality. Game Sound Mode offers 3 exciting sound settings - Speed mode gets the adrenaline going in high-speed driving and flying games while Punch mode adds power to the punch in hand-to-hand combat games. Finally Blast mode lets you experience the full explosive effects of battle games. A Game Mix function, MIX-IT, available on Mini Hi-Fi Systems, allows game sounds to be mixed with a favorite CD track, radio station or external audio player.

### MAX Sound

MAX Sound technology produces an instant boost in bass, maximizes volume performance, and instantly creates the most impressive listening experience with just a touch of the MAX Sound button. The MAX Sound electronic circuitry calibrates the existing sound and volume setting, and instantly boosts bass and volume to a maximum level without distortion. Both sound spectrum and volume get noticeably amplified, creating a potent audio boost that will add mileage to any music. MAX Sound lets you get the most from your audio system without having to alter complicated equalizer settings.

### Vertical Positioning

Vertical Positioning saves space and enhances the aesthetics of your set by giving you the choice of positioning your CD Soundmachine in either the conventional horizontal position or in the attractive, space-saving vertical position. Innovative technology and design ensure that the system works just as well in a vertical orientation as in a horizontal one. In addition, a specially designed CD Soundmachine stand holds the set firmly in place so you can enjoy high quality performance in a vertical position.

UPC 0 3784994532 2 (17)

