

Philips
Micro Hi-Fi System

MP3

MCM510



Play MP3-CD

in sophisticated style with great sound

Specifically designed for one who appreciates the ultimate in technology and style, the system exudes finesse and quality. Unleash the audiophile in you and savor the enhanced sounds from your MP3-CD through powerful, dynamic speakers.

Longer listening, greater enjoyment

- 10 hours of MP3-CD music

Enrich your sound experience

- Incredible Surround™ for enhanced audio enjoyment
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic bass
- 2x25W RMS/2x50W Music Power

Start the day your way

- Wake-Up and Sleep Timer
- Digital tuning with 40 preset stations for extra convenience
- Logic tape deck

Sounds great too

- Elegant wood-finished speakers

PHILIPS
sense and simplicity

Specifications

Sound

- **Output Power:** 2x50 watts music power
- **Sound Enhancement:** Incredible Surround, Digital Sound Control 4 modes, Dynamic Bass Boost

Loudspeakers

- **Main Speaker:** 2 way, Bass Reflex Speaker System, 4" woofer, Piezo tweeter, Speaker grilles detachable

Audio Playback

- **Playback Media:** CD, CD-R, CD-RW, MP3-CD
- **Disc Playback Modes:** 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- **ID3-tag support**
- **Loader Type:** Top
- **Cassette Deck Technology:** Logic
- **Cassette Playback Modes:** Electronic Speed Control, Full Auto Stop, Tape Counter

Audio Recording

- **Recording Media:** Tape
- **Tape Recording Enhancement:** CD Synchro Start Recording, Timer for recording from tuner, Automatic Recording Level

Tuner/Reception/Transmission

- Auto digital tuning
- **RDS:** Station Name, Radio Text, RDS Clock Set

- **Station presets:** 40
- **Tuner Bands:** FM Stereo, MW
- **Tuner Enhancements:** Auto Store

Connectivity

- **Aux in:** Line in
- **Headphone:** 3.5 mm
- **Other connections:** FM Antenna, MW Antenna

Convenience

- **Alarms:** CD Alarm, Radio Alarm, Tape alarm, Sleep timer
- **Clock:** On main display
- **Display Type:** FTD
- **Eco Power Standby:** 1 watt

Accessories

- **Included Accessories:** FM/MW Antenna
- **Remote control:** 21 key

Dimensions

- **Set dimensions (W x H x D):**
175 x 254 x 315 mm
- **Main speaker dimensions (W x H x D):**
175 x 254 x 214 mm
- **Packaging dimensions (W x H x D):**
408 x 348 x 524 mm
- **Weight incl. Packaging:** 12.9 kg

Product highlights

10 hours of MP3-CD music

MP3 stands for "MPEG 1 Audio layer-3". MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

Incredible Surround™

Incredible Surround is an audio technology from Philips that dramatically magnifies the sound field to immerse you in the audio. Using state-of-the-art electronic phase shifting, Incredible Surround mixes sounds from left and right in such a way that it expands the virtual distance between the two speakers. This wider spread greatly enhances the stereo effect and creates a more natural sound dimension. Incredible Surround allows you to experience total surround with greater depth and width of sound, without the use of additional speakers.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2007-12-06

Version: 2.0

12 NC: 9073 100 12583
EAN: 87 10895 88303 0

© 2007 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com