



Philips
DVD player

Karaoke

DVP3005K



See, hear, play everything

Does size matter? Ever heard of less is more? Introducing the best value DVD player. No complications! Just a simple set that plays practically any disc format, including your digital photos with absolutely no compromise to picture quality.

Great audio and video performance

- Progressive Scan component video for optimized image quality
- 12-bit/108MHz video processing for sharp and natural images
- High quality outputs for analog and digital audio

Play it all

- Movies: DVD, DVD+R/RW, DVD-R/RW, (S)VCD
- Music: CD, CD-R/RW and MP3-CD
- Photos: Picture CD (JPEG)

Fits everywhere, goes anywhere

- Compact design
- Ultra-slim design

Your personal karaoke show

- Karaoke for endless singing entertainment

PHILIPS

Highlights

Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

12-bit/108MHz video processing

12-bit Video DAC is a superior Digital-to-Analogue-Converter that preserves every detail of the authentic picture quality. It shows subtle shades and smoother graduation of colors, resulting in a more vibrant and natural picture. The limitation of the usual 10bit DAC

become in particular apparent while using large screens and projectors.

Multi-format Movies

Multi-format playability allows you to play most disc formats for maximum disc compatibility and viewing pleasure.

Multi-format Music

Multi-format playability allows you to play most disc formats for maximum disc compatibility and listening pleasure.

Picture CD (JPEG)

Multi-format playability allows you to view images in the comfort of your living room and

play most disc formats for maximum disc compatibility and viewing pleasure.

Ultra-slim design

The attractive enclosure has a very low profile.

Karaoke

The Karaoke feature on your DVD player provides endless entertainment and maximum audio and singing enjoyment. You can enhance your performance by adding an 'echo' effect to your voice. The key controls allows you to choose the optimal key for your personal vocal range.



Specifications

Picture/Display

- Aspect ratio: 16:9, 4:3
- D/A converter: 12 bit, 108 MHz
- Picture enhancement: Progressive scan, Smart Picture Setting

Sound

- D/A converter: 24 bit, 96 kHz
- Signal to noise ratio: 95 dB
- Distortion and Noise (1kHz): 80 dB
- Crosstalk (1kHz): 90 dB
- Dynamic Range (1kHz): 85 dB
- Sound System: Dolby Digital
- Sound Enhancement: 3D Virtual Surround, Night Mode, Smart Sound

Video Playback

- Playback Media: CD, CD-R, CD-R/CD-RW, Video CD/SVCD, DVD+R, DVD+RW, DVD-R, DVD-RW (Video mode), DVD-Video
- Compression formats: MPEG1, MPEG2
- Video disc playback system: NTSC, PAL

Audio Playback

- Playback Media: CD, CD-R, MP3-CD, CD-RW
- Compression format: PCM, MP3
- MP3 bit rates: 32 - 256 kbps

Still Picture Playback

- Playback Media: Picture CD, DVD+R/+RW
- Picture Compression Format: JPEG
- Picture Enhancement: Flip photos, Rotate,

Slideshow, Zoom

Connectivity

- Other connections: ComponentVideo out, Progressive, Composite video (CVBS) out, Analog audio Left/Right out, Digital coaxial out
- Front / Side connections: Microphone

Convenience

- Child Protection: Parental Control, Child Lock
- On-Screen Display languages: English, Spanish, Brazilian Portuguese
- Karaoke: MIC volume

Power


- Power supply: 50/60 Hz, 110-240V
- Power consumption: 10 W
- Standby power consumption: < 0.8 W

Accessories

- Batteries: 2 x AA
- Cables: 1 x AV Cables
- Remote control: 3141 017 90181
- User Manual: English, Spanish, B-Portuguese
- Warranty Card

Dimensions

- Set dimensions (W x H x D): 360 x 37 x 265 mm
- Set weight: 1.98 kg
- Packaging dimensions (W x H x D): 415 x 82 x 352 mm
- Weight incl. Packaging: 2.98 kg



Issue date 2018-04-11

Version: 7.0.9

12 NC: 8622 810 12175
EAN: 87 10895 85764 2

© 2018 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com