

Philips  
Wireless Hi-Fi Headphone



SHC5102



# Wireless freedom

## Fully rechargeable

No more hassle with the cables; you can feel free to move around at home for music enjoyment. Rechargeable with a lightweight design, it's comfortable for extended use.

### The perfect wireless listening experience

- 32 mm speaker driver delivers high-performance sound
- FM Wireless transmission for freedom of movement

### Comfortable for long use

- Self-adjusting inner headband
- Lightweight design improves comfort for prolonged use.

### Convenience

- 2 headphones means you can share your music with a friend
- Choose from 2 channels to minimise interference
- Fully rechargeable

# PHILIPS

# Specifications

## Sound

- Acoustic system: Closed
- Frequency response: 10–20,000 Hz
- Magnet type: Neodymium
- Sensitivity: 100 dB
- Speaker diameter: 32 mm

## Tuner/Reception/Transmission

- Channel separation: > 30 dB
- Pilot tone frequency: 19 kHz
- Effective range: 100 m
- Carrier frequency range: 863.0 - 865.0 MHz
- Modulation: FM
- Number of channels: 2

## Convenience

- Battery charging indication
- Battery low indication
- Double PLL
- Operating time: +/- 15 hours
- Automatic power off

## Power

- Power supply headphone: 2 x 1.5 V NiMH R03/AAA
- Power supply transmitter: AC/DC adapter 12 V/200 mA

## Outer Carton

- EAN: 87 12581 55815 4
- Number of consumer packages: 3
- Gross weight: 4.06 kg
- Outer carton (L x W x H): 47.5 x 26 x 32.5 cm
- Net weight: 1.854 kg
- Tare weight: 2.206 kg

## Packaging dimensions

- Packaging dimensions (W x H x D): 24 x 32 x 15 cm
- Gross weight: 1.086 kg
- Net weight: 0.618 kg
- Tare weight: 0.468 kg
- Number of products included: 1
- Packaging type: Carton
- EAN: 69 23410 70500 3

# Highlights

## Lightweight design



The durable, lightweight quality materials enhance comfort for extended wearing.

## 32 mm speaker driver

The 32 mm speaker driver is a compact yet powerful element for delivering non-distorted sound with any given input power.

## FM Wireless transmission

With high-frequency FM wireless transmission, which can even pass through walls, you can even listen to your music when you're in another room.

## Self-adjusting inner headband

Typically, headphones worn outdoors are adjustable by sliding an extendable headband into position. This can be inconvenient as it usually has to be done every time you use them. But now you can get your music fix faster and easier thanks to the flexible, self-adjusting inner headband on these headphones, which automatically adjusts to your head's shape and size.

## 2 headphones included

With two headphone sets, you can share the 'personal' listening experience with a friend.

## 2 transmission channels

With a choice of two transmission channels your listening pleasure is protected because you can easily switch to the one with the best reception.

## Fully rechargeable

The headphones are designed to be used with rechargeable batteries. No worries about cost for repeated use.



Issue date 2014-03-11

Version: 4.1.5

12 NC: 8670 000 66508  
EAN: 69 23410 70500 3

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)