

Philips
Micro Hi-Fi System

• Dock for iPod

DCM276



Obsessed with sound

Sound that fits your home

Playback your iPod music in superb sound while recharging it with the Philips sleek micro music system. The flat, compact design is also wall-mountable to complement any interior. USB Direct for added playback options.

Enjoy your music from multiple sources

- Play and charge your iPod simultaneously
- Enjoy MP3/WMA music directly from your portable USB drives
- FM digital tuning to preset up to 20 stations
- Play MP3/WMA-CD, CD and CD-RW

Enrich your sound experience

- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 10 W RMS total output power

Design that blends into your interior(s)

- Stylish slim design with table-stand and wall-mount options
- Motorised sliding front door adding style and elegance



asimpleswitch.com



asimpleswitch.com

PHILIPS

Highlights

Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost



Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can

enjoy consistent sound even when you turn down the volume.

Play and charge your iPod



Enjoy your favourite MP3 music while charging your iPod! The dock lets you connect your iPod directly to the Docking entertainment system so you can listen to your favourite music in superb quality. It also charges your iPod while it plays so you can enjoy your music and not have to worry about your iPod battery running out. Use the remote control to navigate, select and playback the music stored on your iPod. The Docking entertainment system automatically charges your iPod while it is docked.

Table-stand/wall-mount options



The perfect combination of a slim and versatile design, your Philips audio system is cleverly designed to blend into your living space. The base of the audio system is a stand so the system can sit securely and nicely on any shelf

or cabinet. When wall mounted you have all the same flexibility of the freestanding stand.

USB Direct for MP3/WMA music



Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favourite moments with family and friends.



Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas — Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.



Specifications

Sound

- Sound enhancement: digital sound control 4 modes, Dynamic Bass Boost
- Volume control: up/down
- Output power: 2 x 5 W RMS

Loudspeakers

- No. of built-in speakers: 2
- Speaker drivers: 4" woofer
- Speaker types: bass reflex speaker system

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD, USB flash drive
- Disc playback modes: fast forward/reverse, next/previous track search, repeat/shuffle/programme
- Others: ID3-tag support
- USB Direct playback modes: fast reverse/fast forward, play/pause, previous/next, programme play, repeat, shuffle, stop
- Docking playback modes: fast forward and reverse, next and previous track, play and pause

Tuner/Reception/Transmission

- Tuner bands: FM stereo
- Station presets: 20
- Antenna: FM antenna
- Tuner enhancement: auto digital tuning, auto scan

Connectivity

- Audio/Video output: Headphone (3.5 mm)
- MP3 Link: 3.5 mm stereo line in

Convenience

- Alarms: CD alarm, radio alarm, USB alarm, iPod

- alarm
- Loader type: front, motorised
- Clock: on main display, sleep timer
- Charging device: iPod
- Display type: LCD display

Accessories

- Cables/Connection: *Flat pin adapter, MP3 Link cable
- Remote control
- Others: Quick start guide
- User Manual: B-Portuguese, Spanish
- Warranty: Worldwide Guarantee booklet

Dimensions

- Gross weight: 5.14 kg
- Main unit depth: 102 mm
- Main unit height: 238 mm
- Packaging depth: 159 mm
- Main unit width: 542 mm
- Packaging height: 310 mm
- Packaging width: 614 mm

Power

- Power supply: 110 - 127 V and 220 - 240 V AC voltage selectable

iPod compatibility

- Compatible with: iPod, iPod 5th generation, iPod classic, iPod mini, iPod nano 1st generation, iPod nano 2nd generation, iPod nano 3rd generation, iPod nano 4th generation, iPod touch, iPod touch 2nd generation, iPod with colour display



Issue date 2013-05-10

Version: 4.0.2

12 NC: 8670 000 58128
EAN: 87 12581 51505 8

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com

* Avoid extensive use of the set at a volume higher than 85 decibels because this may damage your hearing.
* Adapter supplied is needed for all Latin American countries, except in Brazil.