Portable DAB and FM Radio

DAB and FM Radio; More Stations, Digital Sound

Hi Quality Digital Audio

Tune into DAB and FM radio to enjoy a myriad of radio stations in crystal clear digital sound. DA1000 offers fast, precise tuning through 20 preset stations with a handy joystick - all packaged in a sleek, portable design.

Crystal clear digital radio

- Tune in to near CD-quality radio stations
- DAB and FM compatible tuner
- Six EQ settings for optimized listening

Long play time, rechargeable

- Up to 10 hours playback time
- Rechargeable batteries
- Backlit LCD for easy viewing

Fast and accurate tuning

- Digital tuner with 20-station presets
- · Autostore programming for automatic radio tuning
- Joystick control for easy navigation















DIGITAL TÜNER

Portable DAB and FM Radio

DA1000

Technical specifications

Sound

- Output power (RMS): 3mW
- Sound system: Stereo
- Sound enhancement technology:
 Site amount of a statistic DA
- Six presets equzlizer (only in DAB mode) • Volume control: Digital Up/Down

Tuner / Reception

- Tuning technology: DAB (Digital Audio Broadcasting) Digital FM tuner
- Station presets: 20
 DAB enhancements: Six presets equalizer Easy information navigation
- Signal strength indicator • Antenna:
- External antenna for DAB/FM reception • Turner bands:
- DAB band III (/05 version) DAB band III L (/00C version) FM stereo

Connectivity

- Headphone socket
- DC in

Convenience

- Clock (only in DAB mode)
- Display: Dot matrix LCD display
- Backlight: White

Accessories

- AC/DC adaptor: Charging adaptor (AY3194)
- Batteries:
- $2 \times AA$ rechargeable batteries (AY3362)
- Headphone: 1 x 3.5mm (HE570/77)
- Carrying pouch (AY4206)

Power

- DC supply
- Battery type: 2 x 1.5V, AA/R6/LM-3 cell

Dimensions

- Packaging type: Clamshell
- Product dimensions (WxHxD):
- 60 x 111 x 21 mm
- Product weight: 0.1 kgPackage dimensions (WxHxD):
- 223 x 273 x 68 mm
- Weight incl packaging: 0.47 kg
- Quantity/Master carton: 3

Product highlights

Digital Audio Broadcasting

Digital Audio Broadcasting (DAB) is the latest in digital radio technology. It allows you to enjoy your favorite radio stations in crystal clear, near CD-quality sound. What's more, you get an even wider choice of radio stations and radio hiss caused by signal interference due to obstructing mountains, high-rise buildings and weather become a thing of the past. Since the DAB radio signal is all digital, stations can also transmit text such as program information, news, and sports scores, as well as pictures and even videos direct to your radio set. Radio never sounded so good.

Digital Tuner

Depending on the audio device, Digital Tuner lets you tune up to a maximum of 40 radio stations, memorizes up to 10 tuner presets, or delivers the 'best 10' FM stations based on reception quality. Digital Tuner scans through frequencies and locks on to each station located. By allocating favorite stations a preset number, Digital Tuner makes it quick and easy to return to those stations time and again without having to remember radio frequencies.

Equalizer

Equalizer allows you to select preset modes that optimize certain frequency bands to enhance specific music styles. Players with Equalizer, utilize graphic equalizing technology to automatically set the optimum sound frequency balance for a chosen music style – from Rock and Jazz to Classic and Normal modes. The Equalizer allows you to enjoy the optimum sound depending on the music style.



Printed in Hong Kong 2003-12-05 Specifications are subject to change without notice 2003 © Royal Philips Electronics - All rights reserved www.philips.com