



Philips  
Cordless telephone

DECT3112B

## Get the message

Send SMS from your home phone while watching TV, you never get bored of this stylish looking phone with its amazing sound quality

### Quick & easy SMS

- Text messaging (SMS) for short messages over a fixed line
- Key on handset that gives direct access to all SMS functions
- Display for numbers, letters, icons and drawings

### Benefit from easy-to-use technology

- Pilot key & carousel menu navigates in a menu-in-cycle form
- Clock alarm timer
- Near to real instrument-sounding ringtones

### Multi-pack for ultimate convenience

- Free intercom - Free internal calls between handsets
- Use 2 handsets in separate rooms to transmit noises
- Conference call shares a conversation on several handsets

# PHILIPS

# Specifications

## Picture/Display

- Backlight: No
- Diagonal screen size - tele: 4.0 cm
- Effective viewing area: 31.5x21
- Lines of text: 4

## Sound

- Handset ringers: Polyphonic
- Volume Control: digital

## Convenience

- Auto out of range warning
- Base Station keys: Paging key
- Battery charging indication
- Battery full indication
- Battery low indication
- Call Management: Call Counters, Call Forwarding, Call on Hold, Call Time, Call Waiting, Caller ID, Conference Call, Microphone mute, Missed Calls, Received Calls
- Carousel Icons: Phonebook, SMS, Intercom, Network, Extra, Base, Handset, Call log
- Drop proof: 120 cm
- Ease of Use: Hot Keys, Keypad Lock
- Function: Do not disturb ringer mute, Call cost, Alarm clock, Babysit function, Microphone mute, Conference call, Chain dialling, Direct to Do Not Disturb mode, Short cut keys, Keypad lock, Free handset to handset call
- Handset Keys: Line, Pilot key, Cancel / Recall, Dialling keypad, Loudspeaker, Call log, Phonebook
- Lines of text: 4
- Multi handset capability: Up to 6 handsets
- VIP group with own melody: Yes, 3 groups
- Volume control

## Accessories

- AC/DC Adaptor
- AC/DC Adaptor/Charger
- Batteries: 2 x AAA
- Cables: RJ 11 cable
- Charger: yes, 1 charger
- User Manual

## Related Products

- Package contents: Handset, Base, 2 AAA NiMH Batteries, Telecom Line Cord, Power adapter, User Manual, Warranty leaflet, Sticker

## Green Specifications

- Chemical composition: Nickel-Metal Hydride

- Eco Designed
- Halogen-free housing
- Packaging material: Carton
- Packaging type: Giftbox
- PVC-free product and cables
- User manual: Recycled paper

## Dimensions

- Antenna: Integrated
- Base dimensions: 118x130x60
- Base weight: 180g
- Form Factor: Semi lying on base station
- Handset color: ebony
- Handset dimensions: 120mm
- Handset weight: 100g
- Packaging dimensions (W x H x D): 389 x 90 x 251 mm
- Relative humidity (operation): up to 95% at 40°C
- Relative humidity (storage): up to 95% at 40°C
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -25°C to 70°C

## Power

- Ambient temperature: 5 °C to 40 °C
- Battery Type: NiMH
- Charging time: 14 hours hr
- Kind of Battery: Rechargeable
- Number of batteries: 2
- Power supply base station: 230V
- Radio RF power: <250mW
- Standby time: 200 hours
- Talk time: up to 15 hours

## Network Features

- Antenna: Fast Selection Technology, Integrated on base, Integrated on handset
- Compatible: GAP, PABX
- Dialing: Tone, Pulse
- Messaging: Quick SMS

## Operator Requirements

- SMS
- Name and Caller ID
- Caller ID on call waiting
- Operators services phonebook

## Memory Capacity

- Name & number shared phonebook: 50
- SMS storage capacity: 15
- Call log entries: 10

# Highlights

## Text messaging (SMS)

The Short Message Service (SMS) is a mechanism for delivery of short messages which can have up to 160 characters of text. These 160 characters are plain text in nature and can be comprised of words, numbers or an alphanumeric combination. The Eatoni@LetterWise predictive text editor helps you to write text messages more quickly. With its unique SMS system you can receive up to 200 messages in 10 different mailboxes. Greeting to a loved one, a quick reminder about an important meeting, ...all this can now be put in a SMS and sent over the fixed network.

## Direct SMS key

No need to go through various menus when writing or reading SMS. The direct SMS key makes messaging more convenient and even faster.

## Full graphic display

This type of displays makes it easier to use your phone, thanks to the good quality and legibility of the characters. It also gives you more freedom in communication from your home. Now you can combine text with images or numbers, when sending an SMS for example.

## Pilot key & carousel menu

The pilot key navigation system allows easy navigation and settings. The pilot key is a roller on the left side of the phone that can be scrolled up and down and pressed in the middle. It commands the Carousel menu which is a circular loop of menu icons displayed on the screen.

## Clock alarm timer

Clock alarm timer

## Instrumental ringtones

Instead of the traditional aggressive "buzzer" ringers, instrumental melodies are a more pleasant way to let you know when someone is calling.

## Free intercom

No need to stop what you are doing and go to give the handset to your son when his friend calls: you can freely and easily call the handset in his bedroom and transfer the call.

## Baby-sit function

Worried about your baby not sleeping? No need to constantly go and check in his bedroom. The baby-sit mode allows you to keep an ear on him wherever you are in the house.

## Conference call function

Thanks to the conference call, there is no need to travel to meet people. Especially useful in a professional environment where several work stations are connected to the same base station, the conference call allows, for example, two colleagues from Paris to communicate with a colleague in China. A conference call allows two handsets to share the same external phone conversation in such a manner that each handset is able to communicate with the two others.



Issue date 2014-02-11

Version: 2.0.4

12 NC: 9961 400 02334  
EAN: 87 10895 82598 6

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)