



## True Wireless Headphones

- Earbuds with in-ear fit
- Super-small charging case
- IPX4 water protection
- Up to 18 hours play time

TAT2206WT/00

# Always ready to go

Is there anything more useful than true wireless headphones with a charging case that fits in the pocket of your slim-fit jeans? These splash- and sweat-resistant give you a secure in-ear fit, great sound, and up to 18 hours play time.

## Benefits

[Small charging case. Up to 18 hours play time.](#)

- IPX4 splash and sweat resistant
- Super-small charging case for up to 12 hours play time
- 6 hours play time. Charge 15 minutes for an extra hour
- Clear sound, punchy bass. 6 mm neodymium drivers

[Extremely convenient. Super comfortable.](#)

- 4 colors. 'Hockey-stick' design
- Secure, comfortable in-ear fit

- Make calls using a single earbud. Mono mode
- Soft silicone ear-tip covers in small, medium, and large

[From favorite playlist to catch-up call](#)

- Integrated controls. Built-in mic. Easy pairing
- Easily wake your phone's voice assistant
- Quick reconnect to your phone when you open the case

# PHILIPS

## Features

### IPX4 splash/sweat resistant



With an IPX4 rating and powerful 6 mm drivers, these headphones let you enjoy great sound in any weather. Fully splash resistant, they won't mind a little sweat and you don't need to worry about getting caught in the rain.

### Super-small charging case



Hit the road with multiple charges in your pocket. You get up to 6 hours play time from a single charge, plus 12 extra hours from a fully charged case. A short 15-minute charge in the case gives you an hour of play time. A full charge of the case takes 2 hours via USB-C.

### Secure, comfortable in-ear fit

You get real comfort thanks to soft, interchangeable silicone ear-tip covers. The ear-tips on each earbud insert securely into your ear canal, creating a perfect seal that diminishes external noise. The 'hockey stick' form factor keeps each earbud secure.

### Mono mode



Taking a lot of calls? You can double your talk time by using one earbud while the other one charges. The mic is automatically assigned to the earbud you're using, and you simply swap over when your current earbud is running low on battery.

### Easy control and pairing

Controls on the earbuds let you pause your playlist, take calls, control volume, and wake your phone's voice assistant. The headphones are ready to pair the instant you switch on Bluetooth.

## Specifications

[field not found 'disclaimer\_text']

### Sound

|                     |                |
|---------------------|----------------|
| Impedance           | 16 Ohm         |
| Speaker diameter    | 6 mm           |
| Sensitivity         | 101 dB (1K Hz) |
| Frequency range     | 20 - 20,000 Hz |
| Maximum power input | 5 mW           |
| Driver type         | Dynamic        |

### Telecommunication

|                     |       |
|---------------------|-------|
| Microphone for call | 1 mic |
|---------------------|-------|

### Connectivity

|                               |                      |
|-------------------------------|----------------------|
| Bluetooth version             | 5.0                  |
| Supported codec               | SBC                  |
| Maximum range                 | Up to 10 m           |
| Bluetooth profiles            | A2DP<br>AVRCP<br>HFP |
| Microphone                    | Built-in microphone  |
| Type of wireless transmission | Bluetooth            |
| Wireless                      | Yes                  |

### Convenience

|                     |        |
|---------------------|--------|
| Water resistance    | IPX4   |
| Mono mode for TWS   | Yes    |
| Type of controls    | Button |
| Automatic power off | Yes    |

### Design

|                       |                  |
|-----------------------|------------------|
| Color                 | White            |
| Wearing style         | In-ear           |
| Ear coupling material | Silicone         |
| Ear fitting           | In-ear           |
| In-ear fitting type   | Silicone ear tip |

### Power

|                             |                            |
|-----------------------------|----------------------------|
| Music play time             | 6 +12 hr                   |
| Talk time                   | 6 hr                       |
| Battery type(Earbud)        | Lithium Polymer (built-in) |
| Battery capacity(Earbud)    | 55mAh                      |
| Battery type(Charging case) | Lithium Polymer (built-in) |
| Battery capacity(Case)      | 350mAh                     |
| Charging time               | 2 hr                       |
| Fast charging time          | 15 mins for 1 hr           |
| Battery life standby time   | 200 hr                     |
| Number of batteries         | 3 pcs                      |
| Battery weight (Total)      | 10.5 g                     |
| Rechargeable                | Yes                        |

### Voice assistant

|                            |        |
|----------------------------|--------|
| Voice assistant support    | Yes    |
| Voice assistant activation | Manual |
| Voice assistant compatible | Yes    |

### Accessories

|                   |                     |
|-------------------|---------------------|
| Charging cable    | USB-C cable, 500 mm |
| Charging case     | yes                 |
| Eartips           | 3 pairs (S/M/L)     |
| Quick Start Guide | Yes                 |

### Outer Carton

|                               |         |
|-------------------------------|---------|
| Number of consumer packagings | 24      |
| Height                        | 25 cm   |
| Width                         | 27.8 cm |
| Length                        | 33.8 cm |

|              |                    |
|--------------|--------------------|
| Gross weight | 4.279 kg           |
| Nett weight  | 1.392 kg           |
| Tare weight  | 2.887 kg           |
| GTIN         | 1 48 95229 11741 6 |

#### Inner Carton

|                               |                    |
|-------------------------------|--------------------|
| Number of consumer packagings | 3                  |
| Height                        | 11 cm              |
| Width                         | 13 cm              |
| Length                        | 16 cm              |
| Gross weight                  | 0.479 kg           |
| Nett weight                   | 0.174 kg           |
| Tare weight                   | 0.305 kg           |
| GTIN                          | 2 48 95229 11741 3 |

#### Packaging dimensions

|                             |     |
|-----------------------------|-----|
| Packaging type              | Box |
| Number of products included | 1   |

|                         |                  |
|-------------------------|------------------|
| Type of shelf placement | Hanging          |
| Height                  | 17.2 cm          |
| Width                   | 9.5 cm           |
| Depth                   | 4 cm             |
| Nett weight             | 0.058 kg         |
| Gross weight            | 0.13 kg          |
| Tare weight             | 0.072 kg         |
| EAN                     | 48 95229 11741 9 |

#### Product dimensions

|        |          |
|--------|----------|
| Height | 4.57 cm  |
| Width  | 5.7 cm   |
| Depth  | 3.1 cm   |
| Weight | 0.037 kg |

#### UPC

|     |                 |
|-----|-----------------|
| UPC | 8 40063 20182 8 |
|-----|-----------------|



data subject to change  
2023, June 20

Version: 7.0.3  
EAN: 4895229117419

© 2023 Koninklijke Philips N.V.  
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

[www.philips.com](http://www.philips.com)