

Philips
MP3 portable speaker

- Universal 3.5mm



SBA3000

Exceptional bass

for music enjoyment on the go

Move with your music! Enjoy stereo sound wherever you go on a travel speaker with rich bass performance. Secure the line-in cable to use as a lanyard for easy portability. Inside, a digital amplifier eliminates mobile-phone interference.

Enjoy your music in stereo

- Lightweight, portable design for music enjoyment anytime
- Mobile phone shielding technology for static-free sound
- Universal: works via your device's 3.5mm headphone jack

Take your music with you

- 30 hours of continuous play for worry-free enjoyment
- Battery powered for portability
- Carrying pouch to protect your speakers when not in use
- Line-in cable becomes a lanyard for easy portability

Powerful Sound

- Dynamic bass boost - hear the deepest, richest bass
- Class 'D' digital amplifier for quality sound performance
- Incredible Surround™ for enhanced audio enjoyment



Great sound
on the go
Un son exceptionnel
où que vous alliez.



PHILIPS

Highlights

Dynamic bass boost



Innovative technology delivers unbelievably deep, rich bass from compact speakers. Dynamic bass boost emphasizes the bass content of the music throughout the range of volume settings from low to high – at the touch of a button!

30 hours of continuous play

Powered by batteries, this speaker offers up to 30 hours of continuous play for worry-free enjoyment when you're listening to your music on the go.

Battery powered

Powered by batteries, it's easy to take with you for enjoyment on the go - anywhere and everywhere.

Carrying pouch



Look after your speaker and stop the cable getting tangled by storing it in this handy soft pouch when not in use.

Class 'D' Amplifier

Class 'D' Digital Amplifier takes an analog signal, converts it into a digital signal and then amplifies the signal digitally. The signal then enters a demodulation filter to give the final output. The amplified digital output delivers all the advantages of digital audio, including improved sound quality. In addition, Class 'D' Digital Amplifier has greater than 90% efficiency

compared to traditional AB amplifiers. This high efficiency translates into a powerful amplifier with a small footprint.

Incredible Surround™

Incredible Surround is an audio technology from Philips that dramatically magnifies the sound field to immerse you in the audio. Using state-of-the-art electronic phase shifting, Incredible Surround mixes sounds from left and right in such a way that it expands the virtual distance between the two speakers. This wider spread greatly enhances the stereo effect and creates a more natural sound dimension. Incredible Surround allows you to experience total surround with greater depth and width of sound, without the use of additional speakers.

Lightweight, portable design



The durable, lightweight material and design mean you can carry the speakers with you wherever you go.

Line-in doubles as lanyard

These speakers are ready to go! When it's time to take your music on the go, reconnect the line-in cable and secure it in place to use as a convenient lanyard.

Mobile phone shielding

Mobile phone shielding technology is an advanced circuitry design that cuts out mobile phone interference to ensure static free sound

Universal 3.5mm headphone jack

Plug and play with any of your mobile devices that have a 3.5mm headphone jack – iPod, iPhone, GoGear, MP3 players, laptops, netbooks, music phones and more.

Specifications

Design and finishing

- Color(s): Black

Accessories

- Carrying case: carrying case included
- Batteries: not included

Sound

- Frequency response: 150 - 16,000 Hz
- Impedance: 4
- RMS Power rating: 4 W
- Speaker diameter: 40 mm
- Type: Neodymium
- Sound Enhancement: Class "D" Digital Amplifier, Dynamic Bass Boost, Incredible Surround

Power

- Battery type: AA
- Operating time on battery: 30 hr
- Number of batteries: 4

Convenience

- Volume control: volume control feature

Packaging dimensions

- Packaging type: Carton
- Number of products included: 1
- Packaging dimensions (W x H x D): 9.42 x 22.5 x 9.42 cm
- Gross weight: 0.4 kg
- Nett weight: 0.229 kg
- Tare weight: 0.171 kg
- EAN: 87 12581 50193 8

Outer Carton

- Number of consumer packagings: 6
- Outer carton (L x W x H): 31.9 x 24.9 x 21.7 cm
- Gross weight: 3.053 kg
- Nett weight: 1.374 kg
- Tare weight: 1.679 kg
- EAN: 87 12581 50204 1

Inner Carton

- Number of consumer packagings: 2
- Inner carton (L x W x H): 19.7 x 10.2 x 23.6 cm
- Gross weight: 0.909 kg
- Nett weight: 0.458 kg
- Tare weight: 0.451 kg
- EAN: 87 12581 50205 8



Issue date 2013-05-10

Version: 3.1.7

12 NC: 8670 000 55842
EAN: 87 12581 50193 8

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com