

Philips
Headphones

15mm drivers/open-back
Earhook

SHS3300BK



Extra bass

for powerful sound

Enjoy the bass beat sound of ear-clip headphones that designed for comfort, stability and performance.

Always ready to go

- A 1.2m long cable that is ideal for outdoor use

Made to fit you and your lifestyle

- Ear cushions improve wearing comfort and bass response
- Contoured earhook increase wearing comfort and stability
- Asymmetric cable keeps the cable out the way

Music to your ears

- 27mm speaker driver delivers big sound performance
- Bass beat vents allow air movement for better sound
- Neodymium magnets enhance bass performance and sensitivity

PHILIPS

Specifications

Sound

- Acoustic system: open
- Diaphragm: Mylar dome
- Magnet type: Neodymium
- Type: Dynamic
- Voice coil: copper
- Frequency response: 12 - 22 000 Hz
- Speaker diameter: 15 mm
- Sensitivity: 102 dB
- Maximum power input: 100 mW
- Impedance: 32 ohm

Connectivity

- Type of cable: copper
- Cable Connection: two-parallel, asymmetric
- Finishing of connector: gold-plated
- Cable length: 1.2 m
- Connector: 3.5 mm

Outer Carton

- Length: 35.4 cm
- Number of consumer packagings: 24
- Width: 19.2 cm
- Gross weight: 1.74 kg
- Height: 23.2 cm
- GTIN: 1 69 51613 99170 8
- Nett weight: 0.42 kg
- Tare weight: 1.32 kg

Convenience

- Wearing Style: Earhook

Inner Carton

- Length: 18.2 cm
- Number of consumer packagings: 3
- Width: 8.6 cm
- Height: 11 cm
- Nett weight: 0.0525 kg
- Gross weight: 0.1782 kg
- Tare weight: 0.1257 kg
- GTIN: 2 69 51613 99170 5

Packaging dimensions

- Height: 17 cm
- Packaging type: Blister
- Type of shelf placement: Both
- Width: 9.5 cm
- Depth: 2.6 cm
- Number of products included: 1
- EAN: 69 51613 99170 1
- Gross weight: 0.0452 kg
- Nett weight: 0.0175 kg
- Tare weight: 0.0277 kg

Design

- Color: Black

Dimensions

- Product dimensions (WxDxH): 3.5 cm*1.8 cm*6.1 cm
- Weight: 0.0175 kg

Highlights

27 mm speaker driver

Compact for wearing comfort yet big enough to deliver crisp, powerful sound, the 27 mm speaker driver is a perfect size for non-distorted listening enjoyment.

Bass Beat vents

Bass beat vents allow air movement for better sound with a deep rich bass.

Comfort ear cushions

The special shape and luxurious materials used for the ear cushions of these Philips headphones ensure a perfect fit for maximum comfort. They prevent audio leakage and enhance bass performance too. The ear cushions are shaped in such a way that they perfectly align with the area around a person's ear.

Contoured earhook

The earhook stays put behind your ear even when you're on the move, keeping the earphone comfortably in place and sounding great. It's the part contacting the back of your ears and keeps the headphones on your ears.

Neodymium magnets

Neodymium is the best material for producing a strong magnetic field for greater sensitivity in a voice coil, better bass response and higher overall sound quality.

Asymmetric cabling system

This simple yet highly effective solution to cable tangling works effectively by enabling you to hang the cable behind your neck instead of under your chin.

1.2m cable

The ideal cable length to give you the freedom to put your audio device where you want.

