

Philips  
Digital PhotoFrame

17.8 cm (7")  
16:9 frame ratio

SPF1017



## "...couldn't stop laughing that day!"

Keep your most memorable moments alive year round with Philips Photoframe. This compact frame is easy to use, has lots of storage memory and looks good in any home environment.

### **Top quality display for amazing viewing experience**

- imagen Pro for sharp, vibrant and natural skin colors
- Add new glow to old memories with RadiantColor

### **Simple intuitive operation and great convenience**

- Automatic slideshow from USB or memory card
- Auto photo orientation to fit portrait or landscape modes
- Have fun with collages: display multiple photos in one view

### **Environmentally friendly green design**

- Auto on/off display at pre-set times for power saving

# PHILIPS

# Specifications

## Picture/Display

- Viewing angle: @ C/R > 10, 120° (H) / 100° (V)
- Lifetime, to 50% brightness: 20000 hr
- Aspect ratio: 16:9
- Panel resolution: 480 x 234
- Brightness: 250 cd/m<sup>2</sup>
- Contrast ratio (typical): 300:1

## Connectivity

- USB: USB 2.0 Host, USB 2.0 Slave

## Storage Media

- Built-in memory (RAM): 512MB (for 500 HD photos)
- USB: USB flash drive
- Memory Card Types: Secure Digital (SD), Secure Digital (SDHC), Multimedia Card, xD card, Memory Stick, Memory Stick Pro, Memory Stick Duo (via adaptor), MS Pro Duo (via adaptor)

## Convenience

- Photo format supported: JPEG photo, Up to 10MB JPEG files, Up to 20 Megapixels
- Card Reader: Built-in (1x)
- Placement: Photo auto orientation, Landscape, Portrait
- Buttons and controls: 3 buttons, 4-way navigation key and enter, Power button
- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Album management: Create, Delete, Edit, Rename
- Photo edit: Copy, Delete, Rotate, Zoom & crop
- Slideshow setting: Random, Sequential, Transition effect, Collage (multiple pictures)
- Setup function: Slideshow, Clock display enable/disable, Event reminder with snooze
- Regulatory approvals: CE, GOST, Switzerland
- Other convenience: Kensington lock compatible

## Accessories

- Included accessories: AC-DC Adapter, Quick start guide, User manual on CD-ROM
- User Manual: Arabic, Czech, Danish/Norwegian, Dutch, English, Finnish, French, German, Greek, Italian, Korean, Malay, Polish, Portuguese, Russian, Simplified Chinese, Spanish, Swedish, Traditional Chinese, Turkish

## Dimensions

- Set dimensions with stand (W x H x D): 206.4 x 139.3 x 103 mm
- Weight: 0.345 kg
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -20°C to 70°C

## Power

- Power supply: 100-240VAC, 50/60Hz
- DC output Volt: 9 V
- Power mode supported: AC powered
- DC output Ampere: 1 A
- Power consumption: (System on) 5.6 W

## Packaging dimensions

- Packaging dimensions (W x H x D): 26.1 x 22.2 x 7.8 cm
- Nett weight: 0.6 kg
- Gross weight: 0.799 kg
- Tare weight: 0.199 kg
- EAN: 87 12581 50375 8
- Number of products included: 1
- Packaging type: Carton

## Outer Carton

- Outer carton (L x W x H): 28.3 x 24.3 x 18.8 cm
- Nett weight: 1.2 kg
- Gross weight: 2.1 kg
- Tare weight: 0.9 kg
- GTIN: 1 87 12581 50375 5
- Number of consumer packagings: 2

# Highlights

## imagen Pro for vibrant colors

The unique Philips imagen enhancement technology automatically analyzes your photos to correct color and adjust for optimal contrast. imagen Pro is a more advanced image enhancement which includes the 3 essential elements from imagen to have more color accuracy, color depth and smart contrast. On top of these, imagen Pro offers enhanced skin color, sharper images and flicker-free photo viewing which is very important for still pictures.

## RadiantColor

RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the color on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.

## Automatic slideshow

Automatic slideshows start from any USB drive or memory card for all those moments you don't want to spend time copying photos to your PhotoFrame.

## Auto orientation

Automatic landscape/portrait recognition employs a sensor that recognizes PhotoFrame orientation and displays each photo in its proper mode.

## Multiple-photo collage effect

It's a slideshow effect to show photos in collage form that automatically and randomly compiles different photos together to avoid unattractive borders that may result from photos which are smaller than the screen size.

## Auto on/off display

A timer turns PhotoFrame on and off at the hours you select, reducing energy consumption for the sake of our environment saving up to one third of your PhotoFrame energy costs.



Issue date 2014-02-12

Version: 2.0.5

12 NC: 8670 000 56058  
EAN: 87 12581 50375 8

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)