

Philips  
DVD Micro Theatre

- DivX playback
- component design

MCD139B



## Enjoy great movie experience

Enjoy your favourite movies with The Philips MCD139B. Featuring Progressive Scan for optimised image quality and Dynamic Bass Boost for powerful sound output, you can now enjoy cinematic experience right at your home!

### Enjoy your favourite movies, photos and music

- Play DVD, (S)VCD, MP3-CD, WMA-CD, CD(RW) and Picture CD
- Progressive Scan component video for optimised image quality
- Dolby Digital for ultimate movie experience

### Enrich your sound experience

- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound
- Total 100 W RMS

### Start the day your way

- Wake-up and sleep timer functions
- Digital tuning with 40 pre-set stations for extra convenience

# PHILIPS

# Highlights

## Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, it writes both fields at the same time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

## Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



# Specifications

## Sound

- Output Power: 2 x 25 W + 50 W RMS/1800 W PMPO
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost
- Sound System: Dolby Digital

## Loudspeakers

- Main Speaker: 3" woofer
- Subwoofer type: Passive

## Video Playback

- Playback Media: DVD+RW, DVD-Video, Picture CD, Video CD/SVCD, DivX, DVD
- Disc Playback Modes: A-B Repeat, Angle, PBC, Slow Motion, Zoom, OSD, Resume Playback from Stop, Parental control
- DVD Region.: 1
- Video Enhancement: Progressive Scan

## Audio Playback

- Playback Media: WMA-CD, MP3-CD, CD, CD-R, CD-RW
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/programme, Shuffle Play
- Loader Type: Top

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- Station presets: 40

## Connectivity

- Video Output - Analogue: Component Y Pb Pr (cinch), Composite CVBS (yellow cinch), S-Video (on Hosiden), SCART
- Aux in: 1 x (L/R)/RCA + 1 x Line in
- Other connections: Digital audio coaxial out, FM Antenna, Line out, DIN connection

## Convenience

- Alarms: CD Alarm, Sleep timer, Radio Alarm
- Clock: On main display
- Display Type: White FTD
- OSD Languages: Spanish, French, English, Dutch, German, Italian
- Eco Power Standby: 1 watt

## Accessories

- Included accessories: Composite video cable (Y), FM antenna
- Remote control: 38-key with Lithium battery
- Cables: Din

## Dimensions

- Set dimensions (W x H x D):  
218 x 90 x 221.5 mm
- Main speaker dimensions (W x H x D):  
125 x 250 x 232 mm
- Packaging dimensions (W x H x D):  
550 x 314 x 330 mm
- Subwoofer dimensions (W x H x D):  
147 x 250 x 232 mm
- Weight incl. Packaging: 13 kg



Issue date 2013-05-10

Version: 3.0.5

12 NC: 8670 000 32834  
EAN: 87 12581 35551 7

© 2013 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)