

Philips
In.Sight wireless HD home
monitor

Wi-Fi & HD

Wide angle, Night vision
For smartphone, tablet
Powered by iVideon



M120E

Watch over your home from your smartphone

With HD and night vision

Keep an eye on home with In.Sight wireless HD home monitor via smartphone/tablet. With HD video and night vision, it lets you see clearly your home in daylight/darkness. It's easy to set up and will alert you when it detects motion/sound.

Stay close to loved ones when you're on the move

- Wi-Fi enabled for placement anywhere in your home
- Unlimited live viewing via Wi-Fi/3G/4G LTE
- Extra wide angle lens to let you see more
- InSightHD app available on Apple store and Google Play
- Night vision mode for viewing in the dark

Alerts & notifications for ultimate peace of mind

- Phone receives notification when motion/sound is detected
- Push to talk via smartphone/tablet
- Share monitors with other smartphone/tablet users
- Optional cloud video recording when sound/motion is detected

Easy, safe and secure

- Easy set-up of monitor via QR code
- Video encrypted for secure connection
- Powered by iVideon, a leading firm in video cloud solutions



PHILIPS

Highlights

Wi-Fi enabled



The In.Sight wireless monitor is a Wi-Fi enabled monitor, it uses your home wireless network to stream live video and audio to your smartphone/tablet. A home monitor that you can set up anywhere you like.

Night vision mode



Infrared night vision mode allows you to watch your home even in the dark. When it's dark, infrared light goes on for the monitor to capture clear black and white video. Night vision mode switches on and off automatically, or you can adjust it manually.

Extra-wide angle lens



Philips In.Sight wireless HD home monitor M120, boasts a viewing angle of 102 degrees that shows you more of the room at once, letting you see a lot more than other monitors.

Easy set-up via QR code



Set-up is simple with the In.Sight+ app. The app will generate a QR code for your home Wi-Fi settings. With the QR code, the monitor will automatically pair with your Wi-Fi network, easily and instantly.

Motion/sound notifications



It's impossible to predict when something might happen. In.Sight keeps watching with adjustable motion and sound detection. You will be notified automatically when sound or motion is detected.

Push to talk

With the In.Sight monitor, not only can you keep an eye on your home, but also talk to your loved ones. Simply press "talk" on your smartphone/tablet and communicate at once. What a great way to say hello!

Share with others

Allow your family and friends to view your monitors and let them watch your home for you. The In.Sight+ app lets you share each monitor with other users so that they have access to live video.



Specifications

Lens & Sensor

- Sensor: HD 720p
- Focus mode: Fixed
- View angle: 102 degrees
- Focus range: 0.8M to infinity
- Ambient light sensor: Yes, day/night mode
- Night mode: Infra-Red

Video Quality

- HD/VGA/QVGA streaming
- Formats: H.264 video compression
- White Balance: Automatic white balance
- Exposure: Automatic exposure control

Features

- Wi-Fi: 802.11 b/ g/ n (2.4GHz)
- Motion detection
- Noise detection
- LED indicator
- Night Vision
- Base: Direction adjustable

Software

- App name: InSightHD
- Installation: via App for Android & Apple
- Automatic App update: Yes, for Android & Apple

- System supported: Android 2.3 or above, iOS6 or above
- iPad compatibility: iPad 2 and later
- iPhone compatibility: iPhone 4S and later
- iPod compatibility: iPod Touch 4th gen and later
- Android phone compatibility: Philips recommends Samsung Galaxy S3 performance phones or better

Accessories included

- USB power adapter: 1
- USB cable: Yes, 3m
- Wall mount
- Screws / wall anchors: 2
- Quick Start Guide

Input and Output

- Microphone: High-sensitive, Mono
- USB: Mini-USB port
- Speaker: Built-in

Dimensions

- Packaging dimensions (W x H x D):
158 x 160 x 78 mm
- Product dimensions (W x H x D):
65 x 114 x 65 mm



Issue date 2015-01-23

Version: 9.0.10

12 NC: 8670 001 05448
EAN: 08 71258 16942 65

© 2015 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com