



Philips  
docking speaker

for iPod/iPhone  
Clock display

AD300



## Enjoy music from your iPod/iPhone

On your desk or anywhere else, this dashing docking speaker delivers crystal-clear sound that fills your personal space.

### **Crystal clear sound**

- Bass Reflex Speaker System delivers a powerful, deeper bass

### **Enjoy your favorite music**

- Play and charge your iPod/iPhone simultaneously
- Aux-in connection for your portable MP3 music player

### **Advanced versatility**

- Auto clock synchronization with iPod/iPhone when docked
- LED clock display for clear time viewing

### **Elegant and compact**

- Compact design for any space, any lifestyle

# PHILIPS

Docking speaker  
for iPod/iPhone Clock display

# Highlights

## Compact design

Compact design for any space, any lifestyle

## Auto clock synchronization



When connect and dock, this docking system will automatically synchronize the clock with your iPod/iPhone within a few seconds. With this convenient feature, you do not need to set the time manually.

## Aux-in connection



Aux-in connection for your portable MP3 music player

## Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

## Play & charge your iPod/iPhone



Enjoy your favorite MP3 music while charging your iPod/iPhone! The dock lets you connect your portable device directly to the Docking entertainment system so you can listen to your favorite music in superb sound. It also charges your iPod/iPhone while it plays so you can enjoy your music and not have to worry about your portable player battery running out. The Docking entertainment system automatically charges your portable device while it is docked.

AD300/79

# Specifications

## iPhone compatibility

- Compatible with: iPhone, iPhone 3G, iPhone 3GS, iPhone 4

## iPod compatibility

- Compatible with: iPod, iPod classic, iPod mini, iPod nano, iPod nano 1st generation, iPod nano 2nd generation, iPod nano 3rd generation, iPod nano 4th generation, iPod nano 5th generation, iPod nano 6th generation, iPod touch, iPod touch 2nd generation, iPod touch 2nd gen 8/16/32GB, iPod with color display, iPod 5th generation

## Sound

- Sound system: stereo
- Volume control: up/down
- Output power: 4 W RMS

## Connectivity

- MP3 Link: 3.5mm stereo line in

## Loudspeakers

- Loudspeaker enhancement: bass reflex speaker system

## Power

- Power supply: 100 - 240V AC, 50/60Hz

## Dimensions

- Gross weight: 1.08 kg
- Master carton weight: 2.38 kg
- Master carton quantity: 2
- Weight: 0.84 kg
- Packaging dimensions (W x H x D): 241 x 153 x 136 mm

## Accessories

- AC/DC Adaptor: 110-220V

## Convenience

- Charging device: iPhone, iPod
- Clock: Digital, On main display



Issue date 2014-12-04

Version: 2.0.3

12 NC: 8670 000 84997  
EAN: 87 12581 62633 4

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)