

Philips  
DVD player



DVP3005



## See, hear, play everything

Does size matter? Ever heard of less is more? Introducing the best value DVD player. No complications! Just a simple set that plays practically any disc format, including your digital photos with absolutely no compromise to picture quality.

### Great audio and video performance

- Progressive Scan component video for optimized image quality
- High quality outputs for analog and digital audio

### Play it all

- Movies: DVD, DVD+R/RW, DVD-R/RW, (S)VCD
- Music: CD, CD-R/RW and MP3-CD
- Photos: Picture CD (JPEG)

### Fits everywhere, goes anywhere

- Compact design
- Ultra-slim design

# PHILIPS

# Specifications

## Picture/Display

- Aspect ratio: 16:9, 4:3
- D/A converter: 12 bit, 108 MHz
- Picture enhancement: Progressive scan

## Sound

- D/A converter: 24 bit, 96 kHz
- Signal to noise ratio: 90 dB
- Distortion and Noise (1kHz): 70 dB
- Crosstalk (1kHz): 80 dB
- Dynamic Range (1kHz): 90 dB
- Sound System: Dolby Digital

## Video Playback

- Playback Media: CD, CD-R/CD-RW, Video CD/SVCD, DVD+R, DVD+RW, DVD-R, DVD-RW (Video mode), DVD-Video
- Compression formats: MPEG1, MPEG2
- Video disc playback system: NTSC, PAL

## Audio Playback

- Playback Media: CD, CD-R, MP3-CD, CD-RW
- Compression format: PCM, MP3
- MP3 bit rates: 32 - 256 kbps

## Still Picture Playback

- Playback Media: Picture CD
- Picture Compression Format: JPEG
- Picture Enhancement: Slideshow

## Connectivity

- Other connections: ComponentVideo out, Progressive, Composite video (CVBS) out, Analog audio Left/Right out, Digital coaxial out

## Convenience

- Child Protection: Parental Control
- On-Screen Display languages: English, Malay, Thai

## Power

- Power supply: 50/60 Hz, 110-240V
- Power consumption: 10 W
- Standby power consumption: < 0.8 W

## Accessories

- Batteries: 2 x AA
- Cables: 1 x AV Cables
- Remote control: 3141 017 90221
- User Manual: English, Simplified Chinese, Traditional Chinese, B. Melayu
- Warranty Card

## Dimensions

- Set dimensions (W x H x D): 360 x 37 x 265 mm
- Set weight: 1.98 kg
- Packaging dimensions (W x H x D): 415 x 82 x 352 mm
- Weight incl. Packaging: 2.98 kg

# Highlights

## Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

## Multi-format Movies

Multi-format playability allows you to play most disc formats for maximum disc compatibility and viewing pleasure.

## Multi-format Music

Multi-format playability allows you to play most disc formats for maximum disc compatibility and listening pleasure.

## Picture CD (JPEG)

Multi-format playability allows you to view images in the comfort of your living room and play most disc formats for maximum disc compatibility and viewing pleasure.

## Ultra-slim design

The attractive enclosure has a very low profile.



Issue date 2014-02-10

Version: 5.0.8

12 NC: 8622 810 12596  
EAN: 87 10895 90140 6

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)