

Philips  
Micro Hi-Fi System

MC230



## Unique Style - Great Sound - Wall Mountable

Trendy and progressive, unique innovation and style appeals to you. And so will the vividly chic MC230 with dynamic sound performance packed in a sleek design that can also be wall mounted.

### Enrich your sound experience

- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic bass
- 2x5W RMS/2x10W music power/400W PMPO
- Plays CD, CD-R and CD-RW discs

### Start the day your way

- Wake-Up and Sleep Timer
- Digital tuning with 40 preset stations for extra convenience

### Design that blends into your interior

- Elegant design with motorize sliding front door
- Super sleek and flexible design which can be wall-mounted

**PHILIPS**  
sense and simplicity

# Specifications

## Sound

- Output power (RMS): 2 x 5 W
- Output Power: 2x10 watts music power
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost

## Loudspeakers

- Main Speaker: 2 way, 3" woofer, Bass Reflex Speaker System, Piezo tweeter

## Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: 40-Track Programmable, Repeat/one/all/program, Shuffle Play
- Loader Type: Front, Motorised

## Tuner/Reception/Transmission

- Auto digital tuning
- RDS: Station Name, Program Type, Radio Text, RDS Clock Set
- Station presets: 40
- Tuner Bands: FM Stereo, MW
- Tuner Enhancements: Auto Store

## Connectivity

- Aux in: Line in

- Headphone: 3.5 mm
- Other connections: FM Antenna, MW Antenna

## Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer
- Clock: On main display
- Display Type: LCD
- Backlight color: Blue

## Accessories

- Included Accessories: FM/MW Antenna, Screws for wall mounting x2, Guarantee booklet, Quick Use Guide, Stand
- Remote control: 23-key with battery
- IFU / User Manual: English

## Dimensions

- Set dimensions (W x H x D): 250 x 245 x 96 mm
- Main speaker dimensions (W x H x D): 166 x 245 x 90 mm
- Packaging dimensions (W x H x D): 330 x 313 x 303 mm
- Weight incl. Packaging: 5.3 kg

## Power

- Power supply: 220-240V, 50Hz



# Highlights

## Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2009-03-09

Version: 1.1.5

12 NC: 8670 000 30764  
EAN: 87 12581 33996 8

© 2009 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)