

Philips
Mini Hi-Fi System



FWC5

Rich Sound Experience

Set your sights on the attractive FWC5 Mini Hi-Fi System, which delivers superbly rich sound. You'll appreciate how easy it is to operate and control, just sit back, relax and enjoy your music all day, your way!

Enrich your sound experience

- Full range Bass Reflex Speaker System
- 2x10W RMS / 600W PMPO

Continuous enjoyment of your favorite music

- Dual Tape Deck
- Digital tuning with 30 preset stations for extra convenience

Personalized sound settings

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound

PHILIPS

Specifications

Sound

- Output Power: 2x10W RMS / 600W PMPO
- Sound Enhancement: Digital Sound Control, Bass Boost

Loudspeakers

- Main Speaker: 4" woofer, Full range, Bass Reflex Speaker System

Audio Playback

- Playback Media: CD, CD-R, CD-RW
- CD Playback Enhancements: Introscan, Next/Previous Track, Repeat, Shuffle
- Loader Type: Top
- Number of Discs: 1
- Cassette Deck Technology: Mechanical
- Cassette Playback Modes: Continuous Play
- Number of decks: 2

Audio Recording

- Tape Recording Enhancement: Automatic Recording Level, CD Synchro Start Recording

Tuner/Reception/Transmission

- Auto digital tuning
- Station presets: 32
- Tuner Bands: FM Stereo, MW

Connectivity

- Aux in: Line in
- Headphone: 3.5 mm
- Other connections: MW Antenna

Convenience

- Alarms: Sleep timer
- Clock: On main display
- Display Type: LCD

Accessories

- Included accessories: AC Power Cord, FM/MW Antenna, User Manual
- Remote control: 27-key
- Standard Package Includes: International Guarantee

Dimensions

- Set dimensions (W x H x D): 267 x 298 x 254 mm
- Main speaker dimensions (W x H x D): 183 x 310 x 165 mm
- Packaging dimensions (W x H x D): 321 x 373 x 746 mm
- Weight incl. Packaging: 11.45 kg

Power

- Power supply: 100-240VAC, 50/60Hz



Highlights

Full range Bass Reflex Speaker

Bass Reflex Speakers delivers a deep bass experience. Differ from conventional loudspeakers, the addition of a bass pipe that is acoustically aligned to the woofer optimizes the low frequency roll-off. The result is a deep controlled bass and low distortion. Combined with the response of the woofer, it extends the overall low frequency sounds to create a whole new dimension of deep bass.

2x10W RMS / 600W PMPO

2x10W RMS / 600W PMPO

Dual Tape Deck

Dual Tape Deck

30-preset digital tuning

Digital radio offers you additional music options to your music collection on your Philips audio system. Simply tune into the station that you want to preset, press and hold the preset button to memorize the frequency. With preset radio stations that can be stored, you can quickly access your favorite radio station without having to manually tune the frequencies each time.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2014-02-10

Version: 2.0.3

12 NC: 9073 100 12802
EAN: 87 10895 89616 0

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com