



Philips  
Noise cancellation  
headphones

32mm drivers/closed-back  
On-ear  
Compact folding

SHL3750NC



## More sound, less noise

powerful bass

Be immersed in your music with innovative ActiveShield active noise canceling technology. Pressure-relieving cushions provide long wearing comfort and a compact foldable design is ideal for portability and easy storage.

### Art of Noise Cancellation

- ActiveShield™ noise canceling reduces noise by up to 97%

### Powerful sound

- 32mm neodymium speaker drivers for rich bass
- Closed-back design blocks out noise for noise isolation

### Make life more convenient

- Slim and compact foldable design for easy portability

# PHILIPS

Noise cancellation headphones  
32mm drivers/closed-back On-ear, Compact folding

## Highlights

### 32mm high definition drivers



Finely tuned 32mm neodymium drivers combined with a closed-back acoustic system design and on-ear sealing provide rich bass.

### ActiveShield™



ActiveShield™ active noise canceling technology features two feed-backward microphones used for canceling low frequencies. It detects ambient noise and inverting the sound wave, effectively cancelling it out and converting background noise to silence.

### Closed-back design



Tuned 32mm neodymium drivers combined with a closed-back acoustic system design and on-ear sealing provide an excellent and impressive precision sound.

### Compact folding



Slim and compact foldable design for easy portability on the go.

SHL3750NC/27

## Specifications

### Packaging dimensions

- Packaging dimensions (W x H x D): 19.5 x 20 x 5 cm
- Packaging dimensions (W x H x D): 7.7 x 7.9 x 2.0 inch
- Nett weight: 0.175 kg
- Nett weight: 0.386 lb
- Gross weight: 0.282 kg
- Gross weight: 0.622 lb
- Tare weight: 0.107 kg
- Tare weight: 0.236 lb
- UPC: 8 89446 00428 1
- Number of products included: 1
- Packaging type: Carton
- Type of shelf placement: Both

### Outer Carton

- Outer carton (L x W x H): 20.3 x 16.2 x 21.6 cm
- Outer carton (L x W x H): 8.0 x 6.4 x 8.5 inch
- Nett weight: 0.525 kg
- Nett weight: 1.157 lb
- Gross weight: 0.98 kg
- Gross weight: 2.161 lb
- Tare weight: 0.455 kg
- Tare weight: 1.003 lb
- GTIN: 1 08 89446 00428 8
- Number of consumer packagings: 3

### Sound

- Impedance: 16 Ohm
- Magnet type: Neodymium
- Maximum power input: 30 mW
- Sensitivity: 105 dB
- Speaker diameter: 32 mm
- Acoustic system: Closed
- Diaphragm: PET
- Frequency response: 10 - 22,000 Hz

### Connectivity

- Cable Connection: single sided
- Finishing of connector: gold-plated
- Cable length: 1.2 m
- Connector: 3.5 mm

### Power

- Music playtime: 40 hr
- Standby time: 50 hr



Issue date 2017-03-06

Version: 2.0.8

12 NC: 8670 001 30634  
UPC: 8 89446 00428 1

© 2017 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)